

T1000 Series UPS

INSTALLATION AND OPERATION MANUAL

SINGLE PHASE - 5.2 & 6 KVA



**Rackmount
Configuration**



**Tower
Configuration**

Part # 91074-005
March 2016

Manufactured in the USA

Product Use and Warranty Restrictions

The Toshiba products listed in this document are intended for usage in general electronics applications (computer, personal equipment, office equipment, measuring equipment, industrial robotics, domestic appliances, etc.). These Toshiba products are neither intended nor warranted for usage in equipment that requires extraordinarily high quality and/or reliability or where a malfunction or failure may cause loss of human life or bodily injury (Unintended Usage). Unintended Usage includes atomic energy control instruments, airplane or spaceship instruments, transportation instruments, traffic signal instruments, combustion control instruments, life-support equipment, all types of safety devices, etc. Unintended Usage of Toshiba products listed in this document shall be made at the customer's own risk.

NOTICE

**PLEASE INFORM A TOSHIBA INTERNATIONAL CORPORATION REPRESENTATIVE IN
CASE OF INCONSISTENCIES, OMISSIONS, OR QUESTIONS.**

The instructions contained in this manual are not intended to cover all of the details or variations in equipment, or to provide for every possible contingency concerning installation, operation, or maintenance. Should further information be required or if problems arise which are not covered sufficiently, contact your Toshiba sales office.

The contents of this instruction manual shall not become a part of or modify any prior or existing agreement, commitment, or relationship. The sales contract contains the entire obligation of Toshiba International Corporation/Social Infrastructure Systems Group/Power Electronics Division/UPS Business Unit, hereafter referred to as Toshiba UPS. The warranty contained in the contract between the parties is the sole warranty of Toshiba UPS and any statements contained herein DO NOT create new warranties or modify the existing warranty.

Any electrical or mechanical modifications to this equipment without prior written consent of Toshiba UPS will void all warranties and may void the UL/CUL listing. Unauthorized modifications can also result in personal injury, loss of life, or destruction of the equipment.

QUALIFIED PERSONNEL ONLY

Qualified Personnel are those who have the skills and knowledge relating to the construction, installation, operation, and maintenance of the electrical equipment and have received safety training on the hazards involved (Refer to the latest edition of NFPA 70E for additional safety requirements).

UNINTERRUPTIBLE POWER SYSTEM (UPS)

Please complete the following information and retain for your records.

Unless otherwise specified, the warranty period for the UPS or UPS part is 36 months from the shipment date (see Toshiba International Corporation bill of lading).

Unless otherwise specified, the warranty period for a UPS battery is 24 months from the shipment date (see Toshiba International Corporation bill of lading).

JOB NUMBER

MODEL NUMBER

SERIAL NUMBER

APPLICATION

SHIPMENT DATE

INSTALLATION DATE

INSPECTED BY

Purpose

This manual provides information on how to safely install your Toshiba International Corporation power electronics product. This manual includes a section of general safety instructions that describes the warning labels and symbols that are used throughout the manual. Read the manual completely before installing, operating, or performing maintenance on this equipment.

This manual and the accompanying drawings should be considered a permanent part of the equipment and should be readily available for reference and review. Dimensions shown in the manual are in metric and/or the English customary equivalent.

Toshiba International Corporation reserves the right, without prior notice, to update information, make product changes, or discontinue any product or service identified in this publication.

Toshiba is a registered trademark of the Toshiba Corporation. All other product or trade references appearing in this manual are registered trademarks of their respective owners.

Toshiba International Corporation shall not be liable for direct, indirect, special, or consequential damages resulting from the use of the information contained within this manual.

This manual is copyrighted. No part of this manual may be photocopied or reproduced in any form without the prior written consent of Toshiba International Corporation.

© Copyright 2016 Toshiba International Corporation
All rights reserved.
Printed in the U.S.A.

Toshiba Customer Support Center

Contact the Toshiba Customer Support Center for assistance with application information or for any problems that you may experience with your Uninterruptible Power System (UPS).

Toshiba Customer Support Center

8 a.m. to 5 p.m. (CST) – Monday through Friday
USA Toll Free (877) 867-8773 – Field Service Tech Support
USA Toll Free (855) 803-7087 – Pre-sales Application Support
Fax (713) 896-5212
Email: ToshibaUPS@tic.toshiba.com

You may also contact Toshiba by writing to:

TOSHIBA INTERNATIONAL CORPORATION
SOCIAL INFRASTRUCTURE SYSTEMS GROUP
POWER ELECTRONICS DIVISION - UPS
13131 West Little York Road
Houston, Texas 77041-9990
Attn: T1000 Product Manager

For further information on Toshiba products and services, please visit our website at:

www.toshiba.com/tic/industrial/uninterruptible-power-systems

This page intentionally left blank.

Table of Contents

1. General Safety Instructions.....	1
1.1 Symbols	1
1.2 Signal Words	2
1.3 Regulatory Compliance Statement.....	2
2. Equipment Warning Labels	3
3. Important Safety Instructions.....	5
3.1 Qualified Personnel Only	6
4. Inspection/Storage/Disposal.....	7
4.1 Inspection	7
4.2 Unpacking.....	7
4.3 Storage	7
4.4 Disposal	7
5. Installation Precautions	8
5.1 Conductor Routing and Grounding	9
6. Installation.....	10
6.1 Module Arrangement	10
6.2 System Installation.....	11
6.3 Tower Installation with Cap	12
6.4 Rackmount Installation - Bracket Mounting Holes	13
6.5 4-Post Rack Installation Instructions	13
7. Wiring the System	16
7.1 Layout - Power Module	16
7.2 Layout - Battery Module (w/ Outlet Panel)	17
7.3 Layout - Transformer Module	18
7.4 Power Module Cable Size and Tightening Torque.....	18
8. Operating Precautions	21
9. Control Panel	22
9.1 Control Panel Layout	22
9.2 Light Emitting Diodes (LED)	23
9.3 LCD Display - Open the Main Menu	23
9.4 LCD Display - Menu/Sub-Menu Navigation	24
9.5 LCD Display - Sub-Menu/Parameter Navigation	25
10. UPS Operation	26
10.1 Initial Startup.....	26
10.2 Startup (Normal)	27
10.3 Bypass	27
10.4 Shutdown.....	28

11. System Description	29
11.1 Application and Use	29
11.2 Power Backup	29
11.3 Power Conditioning	29
12. Operating Modes	30
12.1 Static-Bypass (Stop operation)	30
12.2 On-Line (Run operation)	30
12.3 Battery Backup (On batteries)	31
12.4 EPO (Emergency Power Off) Function	31
12.5 Cold Start (On Batteries)	32
12.6 Frequency Conversion Mode (CVCF)	32
12.7 Battery Backup Time and Discharge Process	33
12.8 Battery Low Voltage Tolerances	33
12.9 Battery Recharging	34
12.10 Battery Test	35
13. Control Panel Menu Trees	36
13.1 Control Panel Navigation and Menu Access	36
13.2 Top Menu - Sub-Menu Tree	37
13.3 Monitor Sub-Menu/Parameter Tree	38
13.4 Setting Sub-Menu/Parameter Tree	39
13.5 Records Sub-Menu/Parameter Tree	40
14. Operation	41
14.1 Cold Start	41
14.2 EPO and Remote Stop	41
15. Communication Interfaces	43
15.1 Remote Contacts	43
15.2 (Optional) RemotEye® Network Card	44
15.3 (Optional) Google Chrome™ Browser App	45
15.4 (Optional) EMD	46
16. UPS Protection System	47
16.1 UPS Protection Devices	47
16.2 UPS Protection Devices Fault Response	47
16.3 System Fault Messages	49
16.4 System Warning Messages	50
16.5 System Mode Messages	52
16.6 System Status Messages	53
17. Preventive Maintenance/Parts Replacement	54
17.1 Preventive Maintenance	54
17.2 LCD Display Cleaning	54
17.3 Battery Replacement	54

17.4 Part Replacement	54
18. Shipping Weights/Dimensions	55
18.1 Unit and Shipping Weights	55
18.2 Shipping Dimensions	55
Appendix A: Specifications	A-1
A.1 T1000 POWER MODULE - 6kVA.....	A-1
A.2 T1000 POWER MODULE - 5.2kVA.....	A-6
A.3 T1000 BATTERY MODULE.....	A-11
A.4 T1000 TRANSFORMER MODULE	A-12
Appendix B: T1000 Menu Table.....	B-1
Appendix C: T1000 Dimensional Drawings.....	C-1
Appendix D: T1000 Packing Lists and Kit Contents	D-1
Inter-Module Cabling Identification	D-1
Appendix E: T1000 Optional Installation Kit Instructions	E-1
E.1 Optional 3-Module Tower Cap Kit - 93178	E-1
E.2 Optional Tower Caster Kit - 90508	E-2
E.3 Optional T1000 2-Post Rack Fixed Installation Kit - 92801	E-5
E.4 Optional T1000 4-Post Rack Slide Installation Kit - 92800.....	E-8
E.5 Optional T1000 2-Post Rack Slide Installation Kit - 90400.....	E-11
Index	I-1

This page intentionally left blank.

1. General Safety Instructions

DO NOT attempt to transport, install, operate, maintain or dispose of this equipment until you have read and understood all of the product safety information provided in this manual.

1.1 Symbols

The symbols listed below are used throughout this manual. When symbols are used in this manual they will include important safety information that must be carefully followed.



Safety Alert Symbol indicates that a potential personal injury hazard exists.



Prohibited Symbol indicates **DO NOT** take action.



Mandatory Symbol indicates that the following instruction is required.



Ground Symbol indicates the location of the equipment grounding conductor.



Electrical – Voltage & Shock Hazard Symbol indicates parts inside may cause electric shock.



Explosion Hazard Symbol indicates parts may explode.



Heavy Lift Hazard Symbol indicates object requires two- or more man lift, or lifting aid.

1.2 Signal Words

The signal words listed below are used throughout this manual. When the words DANGER, WARNING, CAUTION and NOTICE are used in this manual they will include important safety information that must be carefully followed.



The word **DANGER** in capital letters preceded by the safety alert symbol indicates that an **imminently hazardous** situation exists, and if not avoided **will result in loss of life or serious injury to personnel**.



The word **WARNING** in capital letters preceded by the safety alert symbol indicates that a **potentially hazardous** situation exists, and if not avoided **may result in loss of life or serious injury to personnel**.



The word **CAUTION** in capital letters preceded by the safety alert symbol indicates that a **potentially hazardous** situation exists, and if not avoided **may result in minor or moderate injury**.



The word **NOTICE** in capital letters without the safety alert symbol indicates a **potentially hazardous** situation exists, and if not avoided **may result in equipment and property damage**.

1.3 Regulatory Compliance Statement

FCC Class A Notice

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy, and if it is not installed and used in accordance with the instruction manual, it may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

Notice: The FCC regulations provide that changes or modifications made to this device that are not approved by Toshiba International Corporation may void the authority granted to the user by the FCC to operate this equipment.

EMC Directive Class A Note

This UPS is commercial in design and not intended for use at anytime in a Residential Environment.

2. Equipment Warning Labels

The following pages show examples of warning labels that may be attached to either the interior or exterior of the Power (UPS), Battery, or Transformer Modules. Do not remove or cover any of the labels. If the labels are damaged or if additional labels are required, contact your equipment representative for additional labels.

These labels in both English and French are placed to provide useful information or to indicate an imminently hazardous situation that may result in severe equipment/property damage, serious injury, or loss of life if instructions are not followed.








LABELS IN ENGLISH	ÉTIQUETTES EN FRANÇAIS
 DANGER AC VOLTAGE This UPS receives power from more than one source. Disconnect all AC sources before performing any service or testing inside this unit 48082	 DANGER TENSION AC Cette UPS est alimentée par plus d'une source. Débrancher toutes les sources AC avant d'effectuer des entretiens ou des tests à l'intérieur de cette unité. 90630
 DANGER RISK OF ELECTRIC SHOCK Capacitors stay charged after power has been shut off. Accidental contact with live parts can cause personal injury and death. Turn off and lock out all power sources. WAIT AT LEAST FIVE (5) MINUTES for power to dissipate, then check voltage before servicing. 57275	 DANGER RISQUE DE CHOC ÉLECTRIQUE Les condensateurs restent chargés après coupure de l'alimentation. Tout contact accidentel avec des composants sous tension électrique peut provoquer des blessures ou la mort. Fermer et verrouiller toutes les sources d'alimentation. ATTENDRE AU MOINS (5) MINUTES pour laisser décharger les condensateurs, puis vérifier la tension électrique avant l'entretien. 90624
 DANGER DC VOLTAGE DC Voltage supplied by batteries is still present after equipment has been turned off and taken off line. Accidental contact with live parts can cause personal injury and death. Disconnect all DC Sources before performing any service or testing in this compartment. 43784	 DANGER TENSION DC Tension DC fournie par des batteries est encore présente après que le matériel a été éteint et mis hors ligne. Tout contact accidentel avec des composants sous tension peut causer des blessures et la mort. Débrancher toutes les sources DC avant d'effectuer des réparations ou des tests dans ce compartiment. 90632

FIGURE 2-1: EQUIPMENT WARNING LABELS

LABELS IN ENGLISH



ÉTIQUETTES EN FRANÇAIS




FIGURE 2-1: (CONT.) EQUIPMENT WARNING LABELS

3. Important Safety Instructions

This manual contains important instructions that should be followed during the installation and maintenance of the UPS and its batteries.

The T1000 Series UPS is a modular single-phase double conversion system. Each of the rackmount modules is 3U (Three Standard Rack Units) high.

UPS systems are not equipped with an over-current protection device nor an output disconnect for the AC output. Circuit breakers should be provided by the user between the UPS Input and utility power, and the UPS output and the load input. This device should be rated as follows:

240/208 VAC RATING*	5.2 kVA	6 kVA
Input Breaker 240 V / 208 V	35	40 A
Output Breaker 240V / 208V	35	40 A

* Ratings are for a 80% rated device.

The nominal battery voltages for these models is as follows:

UNIT	BATTERY VOLTAGE
5.2 kVA	216 Vdc (Nominal) (1 string of 18 x 12V batteries)
6 kVA	216 Vdc (Nominal) (1 string of 18 x 12V batteries)

Servicing the batteries should only be performed by a qualified factory authorized representative who is knowledgeable about batteries and the required precautions. Keep unauthorized personnel away from batteries. To arrange for battery replacement, contact Toshiba Customer Support Center.

1. Turn off, lockout, and tagout all equipment before connecting the power wiring to the equipment or when performing maintenance.
2. The maximum ambient operating temperature is 104 °F (40 °C). UPS will go to Bypass when it overheats.
3. Access panels should only be removed by authorized Toshiba field Service personnel.
4. UPS servicing should be performed by qualified Toshiba representatives only.
5. Battery servicing should be performed by qualified Toshiba representatives only.
6. Contact your Toshiba authorized service center for battery replacement.

3.1 Qualified Personnel Only

Qualified personnel are those who have the skills and knowledge relating to the construction, installation, operation, and maintenance of the electrical equipment and have received safety training on the hazards involved (Refer to the latest edition of NFPA 70E for additional safety requirements).

Qualified personnel shall:

1. Have read the entire operation manual.
2. Be trained and authorized to safely energize, de-energize, ground, lockout and tag circuits and equipment, and clear faults in accordance with established safety practices.
3. Be trained in the proper care and use of protective equipment such as safety shoes, rubber gloves, hard hats, safety glasses, face shields, flash clothing, etc., in accordance with established safety practices.
4. Be trained in rendering first aid.
5. Be knowledgeable about batteries and their required handling and maintenance precautions.

For further information about workplace safety visit www.osha.gov.



Misuse of this equipment may result in human injury and equipment damage. In no event will Toshiba Corporation be responsible or liable for either indirect or consequential damage or injury that may result from the misuse of this equipment.



DO NOT dispose of the battery module in a fire. The batteries inside may explode.



DO NOT open or mutilate the batteries. Released electrolyte is harmful to the eyes and skin and could also be toxic.

To be performed by **Qualified Personnel Only**:

1. Verify that the UPS is off and that the power is disconnected from the power source.
2. Remove watches, rings or other metal objects.
3. Use tools with insulated handles to prevent inadvertent shorts.
4. Wear rubber safety gloves and boots.
5. **DO NOT** place tools or any metal parts on top of batteries.
6. Determine if the battery is inadvertently grounded. If inadvertently grounded, remove source of ground.

 WARNING	
	Contact with any part of a grounded battery can result in electrical shock. The likelihood of shock will be reduced if such grounds are removed prior to installation or maintenance.

4. Inspection/Storage/Disposal

4.1 Inspection

Inspect for shipping damage upon receipt of the UPS. Use caution when removing the unit from the pallet. Refer to labels or documentation attached to packing material.

4.2 Unpacking

Check the unit for loose, broken, bent or otherwise damaged parts. If damage has occurred during shipping, keep all original crating and packing materials for return to the shipping agent. The warranty does not apply to damage incurred during shipping. Ensure that the rated capacity and the model number specified on the nameplate conform to the order specifications.

4.3 Storage

During periods of non-use, the following guidelines are recommended for storage.

Storage Preparation

1. Power up the UPS and allow it to operate with no load for 24 hours to fully charge the batteries.
2. Stop the unit (See Section 12.1 Bypass/Stop Operation).
3. Place the MCCB switch (Fig. 7-1 (1)) in the Off position.

Storing Conditions

- For best results, store the UPS in the original shipping container and place on a wood or metal pallet.
- Storage temperature: -4 – 104 °F (-20 – 40 °C).
- The optimum storage temperature is 70 °F (21 °C). A higher ambient temperature will require recharging more frequently during storage.

Avoid storage locations that:

- Are subject to extreme temperature changes or high humidity.
- Are subject to high levels of dust or metal particles.
- Are subject to excessive vibration.
- Have inclined floor surfaces.

Storage Maintenance

- If stored at an ambient temperature less than 68 °F (20 °C), recharge the batteries every 9 months.
- If stored at an ambient temperature of 68 – 86 °F (20 – 30 °C), recharge the batteries every 6 months.
- If stored at an ambient temperature of 86 – 104 °F (30 – 40 °C), recharge the batteries every 3 months.

4.4 Disposal

Contact your local or state environmental agency for details on disposal of electrical components and packaging in your particular area.

It is illegal to dump lead-acid batteries in landfills or dispose of improperly.

Please help our Earth by contacting the environmental protection agencies in your area, the battery manufacturer, or call Toshiba toll-free at (877) 867-8773 for more information about recycling.

5. Installation Precautions

NOTICE

1. Observe the following environmental restrictions:
 - Install the unit in a well-ventilated location.
 - Install the unit where the ambient temperature is within the range specified in Appendix A - "Specifications".
 - DO NOT install the UPS in areas that are subject to high humidity.
 - DO NOT install the UPS in areas that allow exposure to direct sunlight.
 - DO NOT install the UPS in areas that allow exposure to high levels of airborne dust, metal particles, or flammable gases.
 - DO NOT install the UPS in areas near sources of electrical noise. Ensuring a proper earth ground will reduce the effects of electrical noise and will reduce the potential for electrical shock.
 - DO NOT install the UPS in areas that would allow fluids or any foreign object to get inside the UPS.
2. Install the unit in a stable, level and upright position that is free of excessive vibration.
3. Follow the instructions on the unpacking label affixed to the exterior of the UPS.
4. Tower Unit with Caster Kit Option Only: Once the installation is complete, screw down the UPS leveling feet located next to the front and back casters, until the unit is no longer resting on the casters.
5. The UPS generates and can radiate radio-frequency energy during operation. Although RFI noise filters are installed inside of the unit, there is no guarantee that the UPS will not influence some sensitive devices that are operating near by. If such interference is experienced, the UPS should be installed farther away from the affected equipment and/or powered from a different source than that of the affected equipment.
6. It is the responsibility of the installer of this equipment to provide a suitable disconnect for the Control Panel supplying power to this equipment.

This disconnect must:

Be suitable for the Voltage and Full Load Ampere Rating of all downstream equipment supplied by the Panel;

The supply disconnecting device shall be one of the following types:

- Switch-disconnect, with or without fuses, in accordance with IEC 60947-3, utilization category AC-23B or DC-23B
- As above, except one that has an auxiliary contact that in all cases causes switching devices to break the load circuit before the opening of the main contacts of the disconnect.
- A circuit breaker suitable as an isolation device per IEC 60947-2
- Any other switching device in accordance with an IEC product standard that also meets the isolation requirements of IEC 60947-1 and is appropriate for on-load switching of motors or other inductive loads;

Be approved for use as a disconnect for the country in which this equipment is installed.

Be provided with a Lock Out Tag Out capability in the Off (Down) position.

7. Allow 5 minutes after power is removed for internal capacitors to fully discharge before attempting to service the unit.
8. The user should provide output over-current protection for hardwired UPS systems. See “Appendix A: T1000 Specifications” on page A-1A-2 for the device rating.
9. After ensuring that all power sources are turned off and isolated in accordance with established lockout/tagout procedures, connect the power source wiring of the correct voltage to the input terminals of the UPS.
10. Hardwire Only: Connect the output terminals of the UPS to the load in line with local wiring regulations. Size the branch circuit conductors in accordance with NEC Table 310.16.

5.1 Conductor Routing and Grounding

1. Use separate metal conduits for routing the input power, output power, and control circuits.
2. Follow the wire size and tightening torque specifications listed on Table 7-4.
3. Always ground the unit to reduce the potential for electrical shock and to help reduce electrical noise.
4. A separate ground cable should be run inside the conduit with the input power, output power, and control circuits.

 WARNING	
	METAL OF CONDUIT IS NOT AN ACCEPTABLE GROUND.

6. Installation

6.1 Module Arrangement

The T1000 Series UPS consists of a Power (UPS) module, optional Battery module(s), and optional Transformer module for output other than 240/208 V. These modules can be purchased in either a rack-mount or tower configuration.

Module arrangement is determined by the length of the factory-supplied inter-module cables. The Modules should be arranged in the following order as viewed from the front: top-to-bottom for Rackmount (Fig. 6-1, Fig. 6-2); left-to-right for Tower (Fig. 6-3, Fig. 6-4).

NOTE: If a Transformer module is used, then the battery module(s) may, or may not, have an output panel.




FIGURE 6-1: RACKMOUNT 240V_{OUT} SYSTEM WITH C-13/C-19 PANEL




FIGURE 6-3: TOWER 240V_{OUT} SYSTEM WITH C-13/C-19 PANEL




FIGURE 6-2: RACKMOUNT 120V_{OUT} SYSTEM WITH TRANSFORMER MODULE




FIGURE 6-4: TOWER 120V_{OUT} SYSTEM WITH TRANSFORMER MODULE

6.2 System Installation

The T1000 Series Power (UPS) module, optional Battery module(s), and optional Transformer module can be purchased in either a rackmount or tower configuration. All three modules are a standard 3U (3 Rack Units) tall, and fit a standard 19 in. rack.

TOWER CONFIGURATION:

In the tower configuration, the orientation of the modules are rotated 90 degrees counter-clockwise, placing the ventilation openings on the bottom. A slip-on Tower Cap is used to provide physical stability for systems of two or more tower modules, including tower systems with optional casters. (Figure 6-5)

- **OPTIONAL: TOWER CAPS**

Each 2-Module tower system comes with a Tower Cap that helps maintain physical tower stability. Optional 3-Module Tower Caps are available for larger systems.

- **OPTIONAL: CASTERS**


An optional caster kit may also be purchased with each module to facilitate relocating the system before and after installation.

RACKMOUNT CONFIGURATION:

Each rackmount configuration module ships with a **4-Post Rack Fixed Mounting Kit**, P/N 92802, for mounting the module in a standard 19 inch rack.

Other rack mounting kit configurations are available: (Figure 6-6)

- **OPTIONAL: 2-POST RACK FIXED MOUNTING KIT**
Hardware for mounting system modules in a standard 19 inch 2-post rack. See Appendix E.
- **OPTIONAL: 4-POST RACK SLIDE MOUNTING KIT**
Hardware for mounting system modules in a standard 19 inch 4-post rack with fully extending slide rails. See Appendix E.
- **OPTIONAL: 2-POST RACK SLIDE MOUNTING KIT**
Hardware for mounting system modules in a standard 19 inch 2-post rack with fully extending slide rails. See Appendix E.



**FIGURE 6-5: TOWER
INSTALLATION OPTIONS**



**FIGURE 6-6: RACK
INSTALLATION OPTIONS**

6.3 Tower Installation with Cap

The Tower configuration modules are arranged side by side, and secured by a press-fit cap over the assembly. If the optional Caster Kit is available, see Appendix E2 for installation.

1. Unpack the T1000 modules and set them in the desired location with the faceplates at the top as shown below.
2. Facing the front of the modules, arrange them left to right in the following order (See Fig. 6-1 - 6-4):
 - Transformer Module (if available)
 - Power Module
 - Battery Module with output panel (if available)
 - Second Battery Module without output panel (if available)

NOTE: There is a Tower Cap for 2-, and 3-module tower systems. Fig. 6-7 shows Tower Cap installation for a 2-module system.

3. Press the T1000 Tower Cap over the tower modules (Fig. 6-7).
4. The T1000 tower is ready for interconnecting cable installation.
5. Go to Section 7 for cabling instructions.




FIGURE. 6-7: INSTALL CAP ON TWO MODULE TOWER SYSTEM

6.4 Rackmount Installation - Bracket Mounting Holes

The Power Module, Battery Module, and Transformer Module all come with the mounting bracket holes located symmetrically on each side. See Fig. 6-8 for the hole locations. Table 6-1 lists the mounting hardware for the bracket holes.



FIGURE. 6-8: RACKMOUNT BRACKET MOUNTING HOLES

TABLE 6-1 RACKMOUNT BRACKET MOUNTING HOLES AND HARDWARE

No.	Accepts (per side)	Used for
1	4 x Phillips 8-32 x 1/4"	Mount for front bracket 68844 used for 4-Post fixed mounting
2	3 x Phillips 8-32 x 1/4"	Mount for rear bracket 92746 used for 4-Post Fixed Mounting Brackets (Kit 92802),
3	1 x Phillips 10-32 x 1/2"	Mount for rear bracket 92746 used for 4-Post Fixed Mounting Brackets (Kit 92802),

 CAUTION	
	Heavy object Can cause muscle strain or back injury. Use lifting aids and proper lifting techniques when handling or installing T1000 Modules.

6.5 4-Post Rack Installation Instructions

Use the 4-Post Fixed Rackmount Kit 92802 (1 kit per module) to mount the T1000 module in a 19-inch, 4-Post rack as follows.

Contents - Fixed 4-Post Rack Installation Kit (92802)

- 1 ea.: T1000 Fixed 4-Post Rack Installation Instructions - 94036
- 2 ea.: 68844 - Ear Chassis Mounting
- 2 ea.: 92746 - Bracket, Rear Fixed Mounting, 4-Post, Black

(Hardware Kit 93863)

- 12 ea.: Cage Nut, 1/4"-20
- 12 ea.: Hex bolt, Sems, 1/4"-20 x 5/8"
- 12 ea.: Screw, PHP (Pan Head Phillips) 10-32 x 1/2" St Box
- 4 ea.: Screw, PHP 8-32 x 1/4" St Zi

Prepare the 4-Post Rack

1. Clip the cage nuts (PC76315P501 Cage Nut, 1/4"-20) from the 93863 kit over the rack rail mounting

holes at the desired level. Clip 2 cage nuts spaced vertically 4 in. apart on each Post.

2. If more than one module is being installed for the T1000 system, install the next pair of cage nuts 3 Rack Units (5 1/4") above the first set of cage nuts for the next module.
3. Repeat Steps 1-2 for each T1000 module to be installed. Continue until cage nuts for all the modules in the system have been clipped on the 4-Post rack.

Prepare the Module(s)

4. Attach the front and rear bracket to the left and right sides of the T1000 module as shown in Fig. 6-9. Use the mounting hardware from Kit 93863 to secure the brackets to the mounting holes indicated in Fig. 6-8 and Table 6-1.
5. Secure the Front Brackets, P/N 68844, to the left and right front side of the module at Fig. 6-9 (1) using four Phillips 8-32 x 1/4" screws.
6. Secure the Rear Brackets, P/N 92746, to the left and right rear side of the module at Fig. 6-9 (2) using 1 Phillips 8-32 x 1/4" screw each in the top and bottom slot, and use a Phillips 10-32 x 1/2" in the center slot (Fig. 6-9 (3)).

Install the Module(s) in the 4-Post Rack

CAUTION: Battery Modules weight 150 lb. (68 kg). Use lifting aids and proper lifting techniques.

7. Follow the vertical arrangement of T1000 modules as discussed in Section 6.1. Mount the lowest module in the 4-Post rack to the bottom pair of cage nuts on each Post using the 1/4"-20 x 5/8" hex bolts, (P/N 33798).
8. Repeat Step 7 for the remaining modules, working from bottom to top. (Fig. 6-10)
9. Go to Section 7 for cabling instructions.




FIGURE 6-9: FIXED MOUNTING BRACKETS - 4-POST RACK



FIGURE. 6-10: 4-POST RACK - FIXED

7. Wiring the System

7.1 Layout - Power Module





FIGURE 7-1: POWER MODULE BACK PANEL LAYOUT

TABLE 7-1: POWER MODULE BACK PANEL LAYOUT

No.	Label	Function
1	INPUT MCCB1 208V/240VDC	Main On/Off circuit breaker.
2	REMOTEYE	Cover plate for RemotEye® circuit card slot.
3	REM. CONTACTS	Dry contacts DB9 connector.
4	OUTPUT L6-30R 208/240VAC 25A	Output receptacle for L6-30P cord (alternate output for 208/240 only)
5	EXT. BATTERY	External Battery Module Anderson receptacle.
6	INPUT L N G	Hardwire input terminals <u>L</u> ine, <u>N</u> eutral, and <u>G</u> round. (TB1)
7	REM. STOP	Remote Stop Contacts. (TB4) (10 VDC)
8	EPO 240V	Remote Emergency Power Off (EPO) Contacts. (TB3) (240/208 VAC)
9	OUTPUT L N G	Hardwire output terminals <u>L</u> ine, <u>N</u> eutral, and <u>G</u> round. (TB2)


**FIGURE 7-2: 6KVA POWER MODULE -
HARDWIRED CONFIGURATION
(P/N T1P0A6000GXG, T1P0A6000GXGR3)**

3-Post Input Terminal Block, and one each
3-Post Output Terminal Block and NEMA L6-
30R outlet.



**FIGURE 7-3: 6KVA & 5.2KVA POWER MOD-
ULE WITH LINECORD (-L1) OPTION
(P/N T1P0A6000GXGL1, T1P0A6000GXGR3L1)
(P/N T1P0A5200GXGR3L1)**

6kVA - Input Power Cord #10-3SO 6-50P
5.2kVA - Input Power Cord #10-3SO L6-30P
and two each NEMA L6-30R outlets.



7.2 Layout - Battery Module (w/ Outlet Panel)

Compatible with both the 5.2kVA and 6kVA Power Modules.





FIGURE 7-4: BATTERY MODULE WITH P1 OUTLET PANEL - LAYOUT

TABLE 7-2: BATTERY MODULE - BACK PANEL LAYOUT

No.	Label	Function
1	BATTERY FUSES	Battery Fuses, 4 ea. (500V, 30A)
2	CN12A	Battery cable Anderson Receptacle (w/ Int. Thermistor) - Connect to Power Module "Ext. Battery".
3	CN12B	Battery cable Anderson Receptacle - Connect to second Battery Module CN12A or CN12B
P1 OPTIONAL OUTLET PANEL 91425: C-13 & C-19		
4	OUTPUT 240VAC 15A	Outlet Receptacles: 4 ea. IEC C-19, (250V, 20A N. America., 15A INT.).
5	OUTPUT 240VAC 10A	Outlet Receptacles: 4 ea. IEC C-13, (250V, 10A N.America., 10A INT.).
6	OUTLET FUSES 15A	Outlet Fuses for IEC C-19 receptacles. (250V, 15A)
7	OUTLET FUSES 10A	Outlet Fuses for IEC C-13 receptacles. (500V, 10A)
8	AC OUT FROM UPS	Anderson receptacle for UPS output cable.
P2 OPTIONAL OUTLET PANEL 91427: NEMA L6-20R & L6-30R		
8	AC OUT FROM UPS	Anderson receptacle for UPS output cable.
9	OUTPUT 240VAC 20A	Outlet Receptacles: 2 ea. NEMA L6-20R, (250V, 20A).
10	OUTPUT 240VAC 30A	Outlet Receptacle: 1 ea. NEMA L6-30R, (250V, 30A).
11	OUTLET FUSE 20A	Outlet Fuse for NEMA L6-20R receptacle (250V, 20A).
12	OUTLET FUSE 20A	Outlet Fuse for NEMA L6-20R receptacles (250V, 20A).
13	OUTLET FUSE 30A	Outlet Fuses for NEMA L6-30R receptacle (500/600V, 30A).
14	OUTLET FUSE 30A	Outlet Fuses for NEMA L6-30R receptacles (500/600V, 30A).

FIGURE 7-4: BATTERY MODULE
OUTPUT PANEL P2 - LAYOUT



7.3 Layout - Transformer Module

Compatible with both the 5.2kVA and 6kVA Power Modules.




FIGURE 7-5: TRANSFORMER MODULE - BACK PANEL LAYOUT

TABLE 7-3: TRANSFORMER MODULE BATTERY MODULE - BACK PANEL LAYOUT

No.	Label	Function
1	OUTPUT 120VAC 20A	Output Receptacle Panel: 4 duplex NEMA 5-20R (250V, 20A)
2	OUTPUT FUSES	Fuses, 4 ea. ,(250V, 20A) (4 Line fuses, one for each pair NEMA 5-20R. Total current limit for each pair receptacles is 20A. Total output from all receptacles must not exceed 50 A)
3	AC OUT FROM UPS	Anderson receptacle for UPS output cable.

7.4 Power Module Cable Size and Tightening Torque

The Battery Modules and Transformer modules come with their own inter-module cabling included. See Fig. 7.5.

Only the Power Module Input terminals need to have wiring installed.

The Power Module Output terminal wired using either:

- Factory-supplied inter-module cables
- Customer-supplied hardwire cables

Use the following table to select the recommended wire size and terminal lug tightening torque for I/O wire connections.

TABLE 7-4: POWER MODULE CABLE SIZING AND TERMINAL TORQUE SPECIFICATIONS- HARDWIRE
(USE COPPER 75°C MIN. CONDUCTORS ONLY)

Terminal	Terminal Number	Terminal Capacity (AWG)	Recommended Wire	Stripping Length in (mm)	Tightening Torque lb.-in. (N•m)
			6 kVA		
AC Input Line, Neutral	L, N	24 - 6	10 - 8	0.43 in (11 mm)	11 - 21 (1.2 - 2.4)
AC Input Ground	G	24 - 6	10 - 8		11 - 21 (1.2 - 2.4)
AC Output Line, Neutral	L, N	24 - 6	10 - 8	0.43 in (11 mm)	11 - 21 (1.2 - 2.4)
AC Output Ground	G	24 - 6	10 - 8		11 - 21 (1.2 - 2.4)
EPO Switch	(Plug)	30 - 12	18 - 16	0.27 in (7 mm)	3.5 - 4.4 (0.4 - 0.5)
Remote Switch	(Plug)	30 - 12	18 - 16		3.5 - 4.4 (0.4 - 0.5)




FIGURE 7-5: FACTORY SUPPLIED CABLING GUIDE - W/ 120V XFMR MODULE

TABLE 7-5: 120V SYSTEM CABLING SPECIFICATIONS

No.	Item	Function
1	92855 Battery Connector Cable	Factory Supplied - Connects Power Module EXT BATT to Batt Module BC1 CN12A to using keyed Anderson Connectors.
2	92855 Battery Connector Cable	Factory Supplied - Connects Batt Module BC1 CN12B to either Batt Module BC2 CN12A or Batt Module BC2 CN12B using keyed Anderson Connectors.
3	92858 (240V) and 92883 (208V) Power Module L6-30 Output to Xfmr Module Cable	Both Factory Supplied - L6-30P twistlock to Xfmr Module keyed Anderson Connector.
4	TB2 240V Hardwire Output	User Supplied (two wire plus ground)
5	TB1 240V Hardwire Input	User Supplied (two wire plus ground)




FIGURE 7-6: FACTORY SUPPLIED CABLING GUIDE - W/ BC OUTPUT PANEL

TABLE 7-6: 240V SYSTEM CABLING SPECIFICATIONS

No.	Item	Function
1	92855 DC Connector Cable: Batt Module 1 to Pwr Module	Factory Supplied - Connects Power Module EXT BATT to Batt Module BC1 CN12A to using keyed Anderson Connectors.
2	92855 DC Connector Cable: Batt Module 1 to Batt Module 2	Factory Supplied - Connects Batt Module BC1 CN12B to either Batt Module BC2 CN12A or Batt Module BC2 CN12B using keyed Anderson Connectors.
3	92858 AC Connector Cable: Power Module L6-30R Output to Batt Module Output Panel P1/P2	Both Factory Supplied - L6-30P twistlock to Xfmr Module keyed Anderson Connector.
4	Output L6-30R Receptacle Panel	User Selectable - Can be either a L6-30 Receptacle or a 3-Post, 3 wire terminal 240V output.
5	Output L6-30R Receptacle	Accommodates L6-30P twistlock cord (alternate output for 208/240 only).
6	TB1 240V Hardwire Input	User Supplied (two wire plus ground)

8. Operating Precautions

1. The UPS should not be powered up until the entire operation manual has been read.
2. The voltage of the input power source must operate within the On-line Tolerance range of +10% to -15% to avoid transferring to Bypass. The input frequency must be within the rated input frequency range. Voltages and frequencies outside of the permissible range may activate the internal protection devices.
3. The Bypass can be programmed to accept one of three voltage tolerances without dropping the load.

Bypass Input Voltage Tolerance Selection
+10% to -10%
+10% to -15%
+15% to -20%

4. The UPS should not be used with a load that has a rated input voltage that is smaller than the output voltage of the UPS.
5. DO NOT use the UPS to provide power to motors that require high starting current or with motors that require a long starting time, such as vacuum cleaners and machine tools (oversizing the UPS for locked rotor current would be required).
6. DO NOT insert metal objects or combustible materials in the ventilation slots of the UPS.
7. DO NOT place, hang, or paste any objects on the exterior surfaces of the UPS.
8. The capacitors of the UPS maintain a residual charge for a while after turning the UPS off.
9. DO NOT attempt to disassemble, modify, or repair the UPS. Repairs and servicing should only be performed by Toshiba Field Service personnel.
10. DO NOT remove any covers of the UPS when the power is on.
11. Turn the power on only after installing ALL of the covers.
12. If the UPS should emit smoke, produce an unusual odor, or make sound, turn the power off immediately.
13. Changing/replacing the UPS Batteries should only be performed by Toshiba field service personnel.
14. Warning signs should be placed on or near the load as a notification that the load is being powered by the UPS.
15. Additional warnings and notifications shall be posted at the equipment installation location as deemed required by **Qualified Personnel**.

9. Control Panel

9.1 Control Panel Layout

Fig. 9-1 shows the LCD display and control layout for the T1000 UPS.




FIGURE 9-1: FRONT PANEL LAYOUT

TABLE 9-1: FRONT PANEL LAYOUT

Item #	Description	Item #	Description
1	Four-line by 20 character LCD Display	7	ONLINE/FAULT LED - Indicates UPS is either Online (Green) or experiencing a Fault (Red)
2	▲ UP Push button - Scroll up one entry of display stack (Entries may be one or more lines long)	8	WARNING LED - Lights (Amber) when a Warning occurs
3	▼ DOWN Push button - Scroll down one line of display stack.	9	AC INPUT LED - Lights (Green) when power is applied to the UPS
4	ESC/MUTE Push button - Press to return to previous screen or cancel configuration mode. (In Main screen, re-enables autoscroll) MUTE - Press and hold ~5 sec. to Mute/Unmute the alarm	10	Mini-USB port - Allows direct PC monitoring of UPS performance
5	ENTER/MENU Push button - Press to Enter the highlighted category. In Settings page use to enter configuration mode or confirm changes.	11	Cold Start Switch - Starts UPS in backup mode when utility power is not available. NOTICE If Utility Power is not restored before the batteries are fully discharged, the UPS will shut down. (See Section 12.5)
6	RUN/STOP Push button - Toggle Inverter between On-Line (RUN) and Bypass (STOP) mode		

9.2 Light Emitting Diodes (LED)

The following table describes the front panel LED behaviors and the associated meaning.

TABLE 9-2: FRONT PANEL LED INDICATORS

LED	Behavior	Significance/Meaning
ONLINE/ FAULT	Green - ON	UPS is in On-Line, Backup, or Battery Test mode.
	Green - OFF	UPS in Bypass mode.
	Green - ON	UPS Backup mode ON. (Battery Discharging)
	Red - ON	One or more faults occurred. See <i>Records: Faults</i> for details.
	Red - Flashing	Charger overvoltage occurred.
	Red - OFF	No fault occurred.
WARNING	Amber - ON	Service Call needed, Less than 6 mo. of Battery Life or Battery Life End.
	Amber - Flashing	One or more Warnings occurred. See <i>Records: Warnings</i> for details.
	Amber - OFF	No Warning (Normal, UPS in operation).
AC INPUT	Green - ON	Input voltage is within specified range.
	Green - Flashing	Input voltage is over specified range.
	Green - OFF	No input voltage or low input voltage.

NOTE: Online/Fault LEDs are dual diodes (Red and Green.) Amber is caused by Red and Green LED's turning on together.

9.3 LCD Display - Open the Main Menu


- The LCD Display can display up to four lines of 20 characters across.
 - Each screen is either a Menu or Data display.
 - The right-most column may display an up (↑) and/or down (↓) arrow, indicating more choices in the indicated direction. Selection is made by moving the pointer (→) along the left side of the display, up and down using the up/down push buttons (Fig 9-1 (2) (▲) & (3) (▼).
1. When the UPS initially starts, the STATUS screen will be displayed. Use the down push button (Fig. 9-1(3)) to move the pointer down until the pointer is next to MENU. Press the Select push button (Fig. 9-1(5)).
 2. The ****MENU**** will open.

9.4 LCD Display - Menu/Sub-Menu Navigation

- The LCD Display can display up to four lines of 20 characters across.
- A screen displays either Menu Options or Data parameters.
- The right-most column may display an **up** (↑) and/or **down** (↓) **arrow**, indicating more choices in the indicated direction. Selection is made by moving the **pointer** (>) along the left side of the display, up and down using the up/down push buttons (Fig 9-1 (2 & 3)).

Example:

1. When the main Menu display opens, the selection pointer initially points at **Quick Config**. (Fig. 9-2a) The downward pointing arrow in the right-hand column indicates you are at the top of the sub-menu list, and there is at least one more selection after the current one.



2. Press the down (▼) push button (Fig. 9-1(2)). The selection pointer moves one line down, to **Monitor**. (Fig. 9-2b)

Now the up and down arrows are displayed in the right-hand column. This indicates there is at least one selection above and below the current selection.



3. Pressing the down push button moves the selection pointer to **Settings**. (Fig. 9-2c)



4. Pressing the down push button once more causes the displayed sub-menu entries to move up one line. The new submenu **Records** is displayed in the bottom line and is pointed to by the selection pointer (>). (Fig. 9-2d)



5. **Records** is the last available sub-menu selection under Menu as indicated by the lack of a down arrow in the right hand column.

FIGURE 9-2: MENU DISPLAY

9.5 LCD Display - Sub-Menu/Parameter Navigation

Sub-menus have parameters that can be monitored and/or adjusted.

Example:

1. Open **MENU** and select sub-menu **Settings**, (Fig. 9-3a) by pressing the **ENTER/MENU** push button (Fig. 9-1 (5)).
2. Arrow down to sub-menu **Output** (Fig. 9-3b) and press **ENTER/MENU**.
3. Arrow down to the parameter **Rated Vout*** (Fig. 9-3c) .
4. The parameter values display is different than the Menu/ Sub-menu/Parameter lists.

Each parameter takes two lines:

- The first line is the parameter name.
 - The second line is the parameter value. (Fig. 9-3c)
5. Select the parameter **Rated Vout**. The parameter selection display will open. It will display only one option at a time.
Scroll through the available choices using the up and down push buttons until the correct value is displayed (Fig. 9-3d).
 6. Press **ENTER/MENU** to load the new value. When the new value is accepted, the display returns "Success". (Fig. 9-3e)
 7. Press the **ESC/MUTE** push button (Fig. 9-1(4)) to return to the parameter screen (Fig. 9-3f).
 8. Cycle power to the UPS to implement the new value. Do this for any changes to parameters followed by an asterisks (*).

The shorthand for this operation is expressed: MENU > SETTINGS > OUTPUT > Rated Vout > Rated Vout: 200V




FIGURE 9-3: PARAMETER DISPLAY

10. UPS Operation

10.1 Initial Startup

The following parameters need to be input before connecting the load to the UPS. The most convenient access is to use the **Quick Config** menu using the example in Section 9.4.

See Section 9 for control panel explanations and display navigation.

1. Ensure no loads are connected to the UPS outlets.
2. Apply power to the T1000 UPS System. Switch on MCCB1. The **ONLINE/FAULT** LED will briefly illuminate, then turn off.
3. In Bypass, the UPS **ONLINE/FAULT** LED should be Off, and the **AC INPUT** LED a steady Green.
4. Access the **MENU**, open **QUICK CONFIG**, and ensure the following parameters are set properly. When changing/entering a new value, be sure to press the **ENTER/MENU** push button and verify the screen returns a **Success** message.
 - Input Voltage - Select the input voltage to the UPS.
Path: **MENU > QUICK CONFIG > Rated Vin > Rated Vin: xxxV**
 - Output Voltage - Select the output voltage to the Load.
Path: **MENU > QUICK CONFIG > Rated Vout > Rated Vout: xxxV**
 - Vout Adjust - Increase/decrease the output voltage slightly to compensate for line losses.
Default - 0V
Path: **MENU > QUICK CONFIG > Vout Adjust > Vout Adjust: xxV**
 - Battery Installation Date - Set during factory testing. Reset when battery modules are replaced.
Path: **MENU > QUICK CONFIG > Batt Ins Date > Batt Ins Date: mm/dd/yyyy**
 - UPS Date - Current Date. Set at the factory and backed up by an internal battery. Only change when necessary.
Path: **MENU > QUICK CONFIG > UPS Date > UPS Date: ddd mm/dd/yyyy**
 - UPS Time - Current time. Set at the factory for US Central Standard Time and backed up by an internal battery. Only change when necessary.
Path: **MENU > QUICK CONFIG > UPS Time > UPS Time: hh:mm AM/PM**
 - Enable Batt Test - Enable or disable battery testing. Default - Enable.
Path: **MENU > QUICK CONFIG > En Batt Test* > En Batt Test Sup* > En Batt Test*: Enable/Disable**
5. Press the **ESC/MUTE** push button until the **STATUS** screen is displayed.
6. Leave the Power Module in bypass mode to allow the battery module(s) to charge for 24 hrs. before placing the Power Module online.



ALLOW 24 HOURS FOR THE POWER MODULE TO RECHARGE THE BATTERY MODULE(S) BEFORE PLACING THE UPS IN SERVICE.

7. Place the UPS online by pressing and momentarily holding the **RUN/STOP** push button. The **ONLINE/FAULT** LED should glow steady GREEN.

NOTE: Bypass is automatically disabled if the **Rated Vin** and **Rated Vout** are different.

10.2 Startup (Normal)

Once the initial operating parameters have been set (Section 10.1), the UPS can be started from a shutdown condition by following these steps:

1. Switch on MCCB1. The **ONLINE/FAULT** LED will briefly illuminate, then turn off.
ONLINE/FAULT LED - Off
AC INPUT LED - Steady Green
2. Press and momentarily hold (~2 sec.) the **RUN/STOP** push button until it beeps. The **ONLINE/FAULT** LED should glow steady green.
ONLINE/FAULT LED - Steady Green
AC INPUT LED - Steady Green
3. The UPS is now Online.

10.3 Bypass

The UPS can be placed in Bypass by following these steps:

NOTE: The UPS can be placed in Bypass mode only if the Input and Output voltage parameters are set the same (e.g. 240 Vin/240 Vout, 208 Vin/208 Vout). Bypass is disabled if the Input and Output voltage parameters are different.

UPS is Initially OFF

1. Switch on MCCB1. The **ONLINE/FAULT** LED will briefly illuminate, then turn off. The UPS is in Bypass.
ONLINE/FAULT LED - Off
AC INPUT LED - Steady Green (If the AC INPUT LED is Off, then Bypass has been disabled. See 10.3 NOTE.)

UPS is Initially ONLINE

1. The Online state will show:
ONLINE/FAULT LED - Steady Green
AC INPUT LED - Steady Green
2. Press and momentarily hold (~2 sec.) the **RUN/STOP** push button until it beeps. The **ONLINE/FAULT** LED will turn off.
ONLINE/FAULT LED - Off
AC INPUT LED - Steady Green (If the AC INPUT LED is Off, then Bypass has been disabled. See 10.3 NOTE.)

10.4 Shutdown

The UPS can be Shutdown (turned off) by following these steps:

UPS is Initially ONLINE

1. The Online state will show:

ONLINE/FAULT LED - Steady Green

AC INPUT LED - Steady Green

2. Press and momentarily hold (~2 sec.) the **RUN/STOP** push button until it beeps. The **ONLINE/FAULT** LED will turn off.

ONLINE/FAULT LED - Off

AC INPUT LED - Steady Green *(If the AC INPUT LED is Off, then Bypass has been disabled. See 10.3 NOTE.)*

3. Remove power from the T1000 UPS System. Switch off MCCB1. The **AC POWER** LED will turn off.

ONLINE/FAULT LED - Off

AC INPUT LED - Off

UPS is Initially in BYPASS

1. The Bypass state will show:

ONLINE/FAULT LED - Off

AC INPUT LED - Steady Green

2. Remove power from the T1000 UPS System. Switch off MCCB1. The **AC POWER** LED will turn off.

ONLINE/FAULT LED - Off

AC INPUT LED - Off

UPS is Initially in BACKUP

1. The Backup state will show:

ONLINE/FAULT LED - Steady Green

AC INPUT LED - Off

2. Remove power from the T1000 UPS System. Switch off MCCB1. The **AC POWER** LED will then turn off.

ONLINE/FAULT LED - Off

AC INPUT LED - Off

11. System Description

An uninterruptible power system (UPS) is a system that is installed between the commercial power and the load equipment. The UPS provides steady AC output power during commercial power short-term interruptions such as blackouts or brownouts. This power is provided for a sufficient amount of time so that the load can be shut down in an orderly fashion. This prevents loss of data and possible damage to both hardware and software.

During normal operation, the UPS uses commercial AC power. It absorbs high voltage spikes and transients caused by switching and faults, and the common-mode and normal mode noise which is associated with commercial AC power. The UPS converts it all to clean DC power. From this power, the UPS charges its batteries and generates its own extremely high quality AC waveform output. The result of this process is maximum power conditioning and regulation.

If the AC power supplied to the UPS drops below a specified voltage level, the unit's batteries automatically begin supplying power instead of receiving it. This insures that the loads connected to the UPS continue to receive power with no interruption (as long as the backup batteries hold up). When AC input power becomes available again, operation returns to normal, and the unit's batteries begin to recharge so they will be ready for the next power interruption.

11.1 Application and Use

In Online Mode the Toshiba T1000 UPS provides continuous computer-grade AC power in a compact, high performance, and energy efficient unit. The UPS unit ensures safe and reliable operation of critical office equipment. All units feature an audible alarm which sounds if the battery voltage drops below a specified minimum during use. This is an additional aid to help protect valuable office data banks. All units allow for computer interfacing.

11.2 Power Backup

When an electrical power failure occurs, the UPS's internal batteries automatically supply back-up power to the load without interruption. For example, when used to support a computer, the UPS back-up assures enough additional time to complete the activity and store the data. This allows an orderly shutdown of critical equipment.

The T1000 minimum input voltage, ViUV, is 85% of the nominal input voltage of 240V at full load.

11.3 Power Conditioning

When commercial power is present, the UPS supplies conditioned power to the load while maintaining its batteries in a charged condition. The UPS protects against the normal, everyday problems associated with unreliable commercial power, including power sags, surges, signal interference, and spikes. This protection keeps power-line problems from reaching your load, where they can cause equipment to operate erratically, or damage software and hardware.

During brown-out conditions, where the utility power momentarily drops below the minimum 85% of nominal input voltage, the UPS will transfer to backup mode. Once the input voltage increases above 85% of nominal input voltage, the UPS will automatically retransfer to Online Mode.

12. Operating Modes

12.1 Static-Bypass (Stop operation)

During power up the UPS starts up in Bypass mode except when:

- Performing cold start operation.
- Performing frequency conversion.
- When input and output voltages are unequal causing bypass to be disabled.

If the UPS unit is severely overloaded or develops an internal fault, power flow is automatically switched from the unit's main circuit to the bypass circuit. Power flow through the bypass is shown in the following illustration. This change-over occurs automatically in phase in less than one-quarter cycle of the input waveform. The switching period is not long enough to cause interruptions to occur in most loads.

- If the power flow is transferred to the bypass circuit due to an internal fault the UPS will continue to supply power to the load through the bypass and indicate a system fault message (see "16.3 System Fault Messages" on page 49).
- If the power flow is transferred to the bypass circuit due to an overload condition (see "16.4 System Warning Messages" on page 50), then the power flow will automatically transfer from the UPS's bypass circuit back to the inverter circuit after removing the overload if set to do so (Under **Setting > Status Config & Ctl**, set **En AutoXfer** to **Enable**).




FIGURE 12-1: POWER FLOW IN BYPASS FOR ALL MODELS

NOTE: Bypass will be automatically disabled if the rated input and output voltages or frequencies are different.

12.2 On-Line (Run operation)

The following illustration shows circuit power flow when the UPS is operating normally in the Online Mode. The UPS rectifier, including a boost chopper circuit, converts AC input power to DC power. The boost chopper circuit maintains a constant voltage, with current limiting, for charging the batteries. The inverter section generates a high quality sinusoidal output voltage. The unit's batteries are always maintained in a constantly charged state when the UPS is in the run operation mode.




FIGURE 12-2: POWER FLOW IN ONLINE MODE FOR ALL MODELS

12.3 Battery Backup (On batteries)

The following illustration shows power flow during the battery backup mode. When commercial AC power failures occur, the UPS's batteries instantly begin supplying DC voltage to the UPS's main inverter circuit. This circuit changes (inverts) the DC power into AC power. The AC power is available at the output of the unit.

This back-up process will continue until the UPS's battery voltage drops below a specific minimum level. When this occurs, the batteries will stop supplying power to the load. This minimum level is the rated minimum voltage (V_{min}). The rated battery voltage chart on page 33 shows (V_{min}). The battery backup time and discharge process is explained on page 33.




FIGURE 12-3: POWER FLOW IN BATTERY BACKUP FOR ALL MODELS

12.4 EPO (Emergency Power Off) Function

These units are equipped with terminals for receiving an emergency power-off (EPO) command via a closed-contact switch at a remote location (see Terminal Block Details on Table 7-1, and terminal block location in Section 7.1). This safety feature enables quick shut-down of the UPS's AC input breaker, output and battery circuits.

Usually the emergency power off switch is installed in a central location that is easily accessible to personnel concerned with the operation of the UPS unit and the load equipment connected to it. The EPO function is initiated by pressing the switch to the closed (shutdown) position.

The effect of using the EPO switch is the same whether the UPS unit is in AC input mode, battery backup mode, or the circuit bypass mode. The following figure shows the UPS condition after application of the EPO switch.

NOTE: EPO operation should be limited to no more than 4 operation per minute, or 24 operations per hour. Exceeding this duty cycle will overheat the EPO components




FIGURE 12-4: POWER FLOW AFTER AN EPO COMMAND FOR ALL MODELS

12.5 Cold Start (On Batteries)

The following illustration shows power flow during Cold Start. When the UPS must be started, and utility power is not available, the UPS can be *Cold Started* (the UPS's batteries supply DC voltage to the UPS's main inverter circuit.) This circuit changes (inverts) the DC power into AC power. The AC power is available at the output of the unit.

NOTE: The default frequency mode is set to auto-detect. In auto-detect mode the default output frequency at turn-on and cold-start is 60 Hz.

This battery discharge process will continue until either:

- Utility power is restored and the UPS auto-transfers to online mode,
- The UPS's battery voltage drops below the Battery Shutdown voltage (V_{min}) and the UPS shuts down power to the load and turns itself off. The nominal minimum voltage V_{min} is given in Table 12-1.

NOTE: The Battery-shutdown Voltage is automatically adjusted by the UPS based on load percentage in order to maximize battery life.

The battery backup time and discharge process is explained in Section 12.7 – 12.9.




FIGURE 12-5: POWER FLOW IN BATTERY BACKUP FOR ALL MODELS

12.6 Frequency Conversion Mode (CVCF)

The default Frequency mode is Auto-detect; the Output frequency will be the same as the Input frequency: 60 Hz in and 60 Hz out, or 50 Hz in and 50 Hz out. In Auto-detect the parameter **CVCF** is set to **DISABLED**.

NOTE: Only **ENABLE** parameter **CVCF** if the desired output frequency is different that the input frequency.

To set the UPS for frequency conversion:

1. Access the menu parameter **Settings > Status Config & Ctl > EN CVCS** and select **ENABLED**.
2. Access the menu parameter **Settings > Status Config & Ctl > CVCF Frequency** and select the desired output frequency - either **50.0Hz** or **60.0Hz**.

NOTE: Ensure the load is disconnected before changing the CVCF parameter value.

3. Cycle power to the UPS to save the new parameter settings.

Cold Start in Frequency Conversion Mode

The output frequency will be the selected output frequency **CVCF Frequency**.

12.7 Battery Backup Time and Discharge Process

The UPS battery module will provide approximately 5 minutes of back-up time per battery module when operating at full load at the rated power factor. The exact length of these times will depend on the condition of the batteries, amount and type of load, temperature and other variables. See battery backup time in "Appendix A: T1000 Specifications" on page A-3.

The following illustration graphically shows the battery discharge process at full load conditions.




FIGURE 12-6: BATTERY DISCHARGE CURVES

12.8 Battery Low Voltage Tolerances

Excessive discharge will cause the UPS battery voltage to drop. The chart shown below lists the voltage level at which each UPS low-voltage alarm will sound when loaded to rated full load at 240V and at what level the low-voltage condition will cause the unit to automatically shut down.

TABLE 12-1: VOLTAGE TOLERANCES

UPS Capacity	6 kVA
Nominal voltage (V_{NOM})	216 Vdc
Alarm voltage (V_{LOW})	194 Vdc
Shutdown voltage (V_{MIN})	170 Vdc

12.9 Battery Recharging

The illustration below shows a graphical representation of the UPS battery recharge process after a full discharge.




FIGURE 12-7: BATTERY RECHARGING PROFILE

The recharge process usually consists of three periods.

- During the first period, the current is maintained at approximately 1.0 ampere. This current limit is the maximum value that can be used to charge the batteries (for minimal recharge time) while assuring safety and long battery life.
- In the second period, constant-voltage control starts and current gradually decreases as the batteries charge to their normal fully charged state.
- In the third period, a slight trickle current continues to flow into the batteries to keep them fully charged and floating at the normal Vdc level.

A full recharge usually requires 24 hours (90% recharge in 4 hours) after a complete discharge.

The following chart shows the rated maximum and minimum battery voltages and the charge current for the UPS.

TABLE 12-2: RATED BATTERY VOLTAGES

Model	Vmax (Float)	Vmin	Icharge
6 kVA	246 V	170 V	1.0 A

12.10 Battery Test

See Fig. 9-1 for a detailed description of the LCD display layout and controls for the T1000 UPS.

The T1000 allows the user to conduct automatic battery test on startup, or manual battery tests at daily, weekly, or monthly intervals. The following steps detail the battery test procedures.

Battery Test on Startup:

1. Navigate to **MENU > Setting > Status Config & Ctl > En Batt Test Sup*** and set it to “**Enable**”.
2. Navigate to **MENU > Setting > Status Config & Ctl > En Batt Test*** and select “**Enable**” to allow the battery test to be performed.
3. The Battery Test on Startup is performed only if it is enabled during startup. Restart the UPS to perform the battery test on startup.

Manual Battery Test

A Batt Test can be manually initiated once every interval selected in **Batt Test Freq**.

Batt Test Freq sets an internal lockout timer that prevents manual testing more frequently than the interval selected (0 = Daily, 1 = Weekly, 2 = Monthly). To repeat the test more often, cycle power to the UPS to reset the Batt Test* lockout timer.

The **Batt Test Freq** lockout timer is initiated when a manual test is performed, or after a Batt Test on Startup is enabled, and prevents Battery testing until the timer counts down to zero.

NOTE: If the UPS is connected to the load and the batteries are either depleted or bad, power to the load may be interrupted when a battery test is conducted.

The UPS must be in Online mode.

ENABLE MANUAL BATTERY TESTING

1. Navigate to **MENU > Setting > Status Config & Ctl > En Batt Test*** and select “**Enable**” to allow the battery test to be performed.
2. Navigate to **MENU > Setting > Status Config & Ctl > Batt Test Freq** and select the desired minimum wait time between battery tests: 0 = Daily, 1 = Weekly, 2 = Monthly.

CHECK Batt Test Freq LOCKOUT TIMER

3. Navigate to **MENU > Monitor > Status Config & Ctl > Batt Test Cond.**
 - If the display shows “**Ready for Test**”, test can be initiated. GO TO STEP 4.
 - If the display shows “**Test Prohibit**”, the lockout timer is still counting down and the test can not be initiated. If the test must be performed before the lockout timer clears, cycle power to the UPS, then repeat Step 2.

PERFORM BATTERY TEST

4. Navigate to **MENU > Setting > Status Config & Ctl > Requested State** (the first entry under **Status Config & Ctl**) and select “**Batt Test**”.
 - If the test passes, the display returns to the Monitor screen.
 - If the test fails, the display returns to the Monitor screen and displays BTSTFL in the warning section at the bottom left of the display, and the “Warning” LED blinks until the fault is no longer detected.

Batt Test* failure may be caused by a loose battery cable. Verify the cables are properly connected and rerun the test. If Batt Test* fails again, there is a failure in the Battery Module. Disconnect the battery module from the UPS and re-run the test. This will clear the BTSTFL fault.

13. Control Panel Menu Trees

13.1 Control Panel Navigation and Menu Access

See Fig. 9.1 for a detailed description of the LCD display layout and controls for the T1000 UPS.

There are four options available under the selection **MENU**. Only **Quick Config** and **Settings** allow the user to change parameter settings.

The Menu Trees are laid out in Sections 13.2 – 13.4.

Details of the menu entries are listed in “Appendix B: T1000 Menu Table”.

13.2 Top Menu - Sub-Menu Tree

The opening display offers current status, input/output values, and the MENU selection. Selecting the **MENU** allows the operator the options shown in Fig. 13-2.

Parameter changes can only be made through the **QUICK CONFIG** or **SETTINGS** sub-menus.

Changing a parameter with a single asterisk (*) by it in **QUICK CONFIG** or **SETTING**, such as **EN Batt Test*** and **En Startup Delay***, requires the user to cycle power to the UPS to activate the selected value.




FIGURE 13-1: TOP MENU

13.3 Monitor Sub-Menu/Parameter Tree




FIGURE 13-2: MONITOR MENU AND SUB-MENUS

13.4 Setting Sub-Menu/Parameter Tree

Parameter changes can be made using the SETTINGS menu.




FIGURE 13.3: SETTING MENU AND SUB-MENUS

13.5 Records Sub-Menu/Parameter Tree




FIGURE 13-4: RECORDS SUB-MENU

FAULT RECORD FORMAT

Rec No. nn
mm/dd/yyyy hh:mm:ss
FR:(from mode)(Factory Svc. Code)
TO:(to mode) C:252

Example:

Rec No. 17	↑
01/05/2014 22:28:23	
FR:Bypass B:66	
TO:On-Line C:252	↓

WARNING RECORD FORMAT

Rec No. nn
mm/dd/yyyy hh:mm:ss
F1:0x(Hex) F2:0x(Hex)
F3:0x(Hex)

Example:

Rec No. 170	↑
01/23/2014 10:36:10	
F1:0x0 F2:0x0	
F3:0x80	↓

BACKUP RECORD FORMAT

Rec No. nn
mm/dd/yyyy hh:mm:ss
W1:0x(Hex) W2:0x(Hex)
W3:0x(Hex)

Example:

Rec No. 129	↑
01/23/2014 10:36:10	
W1:0x0 W2:0x4	
W3:0x0	↓

OPERATION RECORD FORMAT

Rec No. nn
mm/dd/yyyy hh:mm:ss
(Message): (Duration)
SOURCE: (Source Code)

Example:

Rec No. 1139	↑
01/12/2014 07:30:47	
ON BATT (SEC): 19	
SOURCE: 2	↓

FIGURE 13-5: RECORD FORMATS

14. Operation

14.1 Cold Start

Cold Start is the process of starting a UPS up in backup mode in the absence of Utility power.

To cold start the T1000, perform the following steps:

NOTE: If the unit is configured for frequency auto-detect (the default shipping mode), the default output frequency for a cold start is 60Hz.

1. Ensure the battery module(s) are plugged in.
2. Ensure the Input/Utility power to the UPS is disconnected.
3. Disconnect the load from the UPS output when performing a cold start. If this is not possible, ensure the load does not exceed the rated output of the UPS.
4. Close the MCCB1 circuit breaker located on the back of the UPS.

NOTE - Ensure the input voltage is set to less than or equal to the output voltage.

5. Press (no holding required) the cold start button located opposite the front panel display. It is partially obscured by the handle recess. (Fig. 14-1)




FIGURE 14-1: COLD START SWITCH LOCATION

6. The transition from Cold Start to Online is automatic once the utility power is connected.

NOTE: After starting in Cold Start, if you press **START/STOP** while still in backup (before utility power is restored) the unit will go into shutdown.

14.2 EPO and Remote Stop

There are two terminal blocks, designated **EPO** and **Rem. Stop**, for connecting switches to the UPS to allow remotely (100 m) Stopping or Shutting Down the UPS by pressing a switch. (See Fig. 14-2)

EPO (Emergency Power Off)

The EPO is triggered by an external switch.



The EPO terminals provide 208/240Vac (same as UPS output terminals). The external switch should be rated for a minimum of 300Vac and 300mA.

When the EPO switch is closed, the Input circuit breaker to the UPS opens and all power to the unit is removed, including backup power from the batteries.

NOTE: EPO operation should be limited to no more than 4 operations per minute, and no more than 24 operations per hour. Exceeding this duty cycle will overheat the EPO circuits.

Remote Stop

The Remote Stop is triggered by an external NO (Normally Open) dry contact switch. Power to the Remote Stop switch is about 10Vdc, and less than 20mA.

When the Remote Stop switch is closed, the UPS transfers from Normal/Backup to Bypass after a 1 – 2 sec. detection delay. (See the diagram below)

When the closed Remote Stop switch is opened, the UPS transfers from Bypass back to it's initial state (Normal/Backup) after a 1 – 2 sec. detection delay.

If the UPS is in bypass when the Remote Stop is closed, no action is taken.




FIGURE 14-2: REMOTE STATUS SHUTDOWN TIMING

15. Communication Interfaces


15.1 Remote Contacts

The remote contacts interface is provided as a set of solid state switching devices. The switches are available through a DB9 male connector on the rear of the UPS. The following chart shows the pin assignment for each signal.

**MAXIMUM CURRENT CARRYING CAPACITY
OF THE SWITCH**

Voltage	Current
48 Vdc peak	70 mA peak
30 Vac rms (42 Vac peak)	50 mA rms (70 mA peak)

**DB9 MALE CONNECTOR OUTLINE
(FACING CONNECTOR)**



Pin	Signal Function	Logic NO - Normally Open NC - Normally Closed	In the UPS
1	Fault Signal	NO - Closed when fault detected	DB9 PCB1 CN2
2	UPS stop common	Backup stop when the level changes from Low (-3 to -15 V) to High (+3 to +15 V)	
3	UPS stop (LAN Shutdown) signal input		
4	Normal input power supply	NO - Closed with normal Input Voltage	
5	Signal common	Common signal return	
6	Bypass operation	NO - Closed during bypass operation	
7	Low Battery	NO - Closed at voltage drop	
8	UPS operation	NO - Closed during inverter operation	
9	Backup signal	NO - Closed at power failure	

NOTE: Pin switches are shown in their inactive states. For example, if battery voltage is low, pin 7 will be connected to pin 5.

FIGURE 15-1: REMOTE CONTACTS PINOUTS

15.2 (Optional) RemotEye® Network Card

The RemotEye is an optional network card for the Toshiba UPS. This card slides into a slot located on the back side (See illustration) of the UPS. The card provides a network, or LAN-based communication interface for the UPS. When installed, the UPS can be managed remotely using the common SNMP and HTTP web-based network protocols. The following diagram shows the flow of the Network Management Station.




FIGURE 15-2: REMOTEEYE INSTALLATION

15.2.1 To install the RemotEye network card, Follow the steps below:

1. The RemotEye network card can be installed with the power module energized or not.
2. Remove the blank cover plate over the RemotEye option slot.
3. Slide the RemotEye printed circuit board into the extension option slot of the UPS.
4. Secure the printed circuit board using the UPS supplied screws.
5. See the RemotEye User Manual to complete the hardware setup and software setting for proper RemotEye operation.

15.3 (Optional) Google Chrome™ Browser App

The Google Chrome browser app “**Toshiba T1000 Series UPS Monitoring Program**” allows any digital device running the Google Chrome browser to monitor the T1000 UPS via a cable to the USB port. The Monitoring app only allows passive monitoring of the UPS performance.

The monitoring app can be run concurrently with the RemotEye Network card.

Requirements: Google Chrome™ web browser and Google Gmail™ webmail account.


1. Download and install the Google Chrome browser if it's not already on your monitoring platform.
2. Create a Google email (Gmail) account if you don't have one.
3. Log in to the Chrome Web Store:
<https://play.google.com/store> (Figure 15-3)
4. Find and select the “**Toshiba T1000 Series UPS Monitoring Program**” app. (See Figure 15-4)
5. Click [+ ADD TO CHROME]. 
6. To monitor a T1000 Series UPS, connect the device running the monitoring program to the T1000 USB port. (See Figure 15-5)
7. Click on the  app icon to start the Monitoring app.



FIGURE 15-4: GOOGLE CHROME APP ICON FOR “TOSHIBA T1000 SERIES UPS MONITORING PROGRAM”




FIGURE 15-3: GOOGLE CHROME APP STORE




FIGURE 15-5: CABLING THE T1000 TO A PLATFORM RUNNING THE “TOSHIBA T1000 SERIES UPS MONITORING PROGRAM”

15.4 (Optional) EMD

The **Environmental Monitoring Device (EMD)** is a monitoring device that provides real time comprehensive remote monitoring of environment temperature and environmental humidity via the RemotEye® Network Card.

The EMD also provides two user-defined dry contacts for additional monitoring.

These dry contacts can be used with devices that provide normally-open or normally-closed results, such as door sensors, smoke detectors, motion detectors, and liquid detectors.




FIGURE 15-4: (OPTIONAL) ENVIRONMENTAL MONITORING MODULE (EMD) - P/N RMTI-EMD-HT




FIGURE 15-5: (OPTIONAL) EMD SENSORS - P/N RMTI-EMD-SENSORS

16. UPS Protection System

16.1 UPS Protection Devices

The following schematic shows the electrical locations of the protection devices on the UPS.




FIGURE 16-1: UPS PROTECTION DEVICE LOCATIONS

16.2 UPS Protection Devices Fault Response

The following charts show the UPS response to common faults.

TABLE 16-1: UPS FAULT PROTECTION FUNCTIONS

Protection Item	Output Overvoltage	Output Undervoltage	Output Overload
LCD Message	VOOV	VOUV	OL110
Cause	Control malfunction; EEPROM error (reprogram or replace)	Control malfunction; Fuse opened; Load issue	Loading that exceeds design parameters
Operation Mode After Fault	Bypass operation – Chopper and inverter are stopped		Inverter OL: Transfer to bypass; Bypass OL: Inverter stopped, chopper continues to boost DC bus
Audible Alarm	Continuous buzzer		See Audible Alarm Functions on page
Visible Alarm	Red Fault LED on		Inverter OL: Fault lamp off Bypass OL: Fault lamp on
Relay Contact Alarm	Fault relay closed Bypass relay closed		Fault relay open; Inverter OL: Bypass relay closed Bypass OL: Bypass relay open
Auto-retransfer*	No		Inverter OL: Yes if bypass is OK Bypass OL: No

TABLE 16-1: UPS FAULT PROTECTION FUNCTIONS (CONT'D)

Protection Item	Ambient Overheat	DC Circuit Overvoltage	DC Circuit Overcurrent
LCD Message	AOH	DCOV	DCOC
Cause	Fan failure; High internal ambient temperature	Chopper malfunction	Inverter/chopper fault
Operation Mode After Fault	Shutdown – No output	Bypass operation – Chopper and inverter are stopped Inverter OL – Transfer to bypass	
Audible Alarm	Continuous buzzer		
Visible Alarm	Red Fault LED on		
Relay Contact Alarm	Fault relay closed Bypass relay closed		
Auto-retransfer	No		

UPS will attempt two sequential Auto-retransfers before requiring manual transfer.

16.3 System Fault Messages

A Fault message is generated when either a fault condition occurs, or a warning condition occurs three times within ten minutes. The table below shows the possible fault messages and what actions need be taken.

If the input voltage is normal when the fault occurs then the UPS will switch immediately to the bypass mode to continuously feed power to the load.

If the fault condition occurs while the input power is abnormal and the UPS is in Bypass mode, the UPS will shut down the output to prevent load equipment damage.

When a Fault condition exists, the red LED on the UPS display panel will illuminate until the fault is cleared.

All faults except EXTBC1 and EXTBC2 are recorded. The fault status can cleared by cycling UPS power (turn off until the display goes blank, then turn on) after the problem has been fixed.

TABLE 16-2: UPS FAULT MESSAGES

Display	Re-corded	Meaning	Action
BYPOH	Y	Bypass Overheat – Overheating condition occurred.	Check unit for blocked or in-operable fan. Lower ambient temperature if it is greater than 104 °F (40 °C). Bypass operation will also cease if overheat condition is not corrected within 1 hr. of inverter shutdown. Try restarting. If condition repeats plan for total shutdown and call for service.
BYPOL	Y	Bypass Overload – UPS is overloaded.	Shut down excess equipment to reduce load.
CHRG OV	Y	Charger Overvoltage – Charger overvoltage condition occurred.	UPS is faulty. Check the UPS operation conditions at time of fault. Not advisable to restart the UPS. Call Toshiba for service.
CL	Y	Current Limit – Load on UPS output exceeds unit specifications.	Reduce load on UPS output.
DCIB	Y	DC Bus Imbalance – DC voltage imbalance occurred.	Possible causes of UPS fault are connection of half-wave rectifier load. Check load and try restarting. If condition persists, call Toshiba for service.
DCOC	Y	DC Bus Overcurrent – DC overcurrent condition occurred.	UPS is faulty. Check the UPS operation conditions at time of fault. Not advisable to restart the UPS. Call Toshiba for service.
DCOV	Y	DC Bus Overvoltage – DC overvoltage condition occurred.	UPS is faulty, input wiring error, input overvoltage or connection of a motor load. Try restarting. If condition persists call Toshiba for service.
DCUVBS	Y	DC Bus Undervoltage during Boostup Mode – DC Bus undervoltage condition occurred.	UPS is faulty. Check the UPS operation conditions at time of fault. Not advisable to restart the UPS. Call Toshiba for service.
DCUVC	Y	DC Bus Undervoltage During Charging Mode – DC Bus undervoltage condition occurred.	UPS is faulty. Check the UPS operation conditions at time of fault. Not advisable to restart the UPS. Call Toshiba for service.
DVCOH	Y	Device Overheat – Overheating condition occurred.	Reduce equipment load to 100% or less and try restarting.

Display	Re-corded	Meaning	Action
EXTBC1	N	1. BC1 Battery String 1, 2, or 3 Loose HCT Connection 2. BC1 Overvoltage Fault 3. BC1 Overcurrent Fault	• Call Toshiba for Service. • Call Toshiba for Service • Call Toshiba for Service
EXTBC2	N	1. BC2 Battery String 1, 2, or 3 Loose HCT Connection 2. BC2 Overvoltage Fault 3. BC2 Overcurrent Fault	• Call Toshiba for Service. • Call Toshiba for Service • Call Toshiba for Service
FSOPEN	Y	Fuse Open.	Replace fuse.
INVOLNR	Y	Inverter Overload (Not Resettable) – Output overload condition occurred.	Reduce equipment load to 100% or less and manually restart the UPS.
INVOLR	Y	Inverter Overload (Resettable) – Output overload condition occurred.	Reduce equipment load to 100% or less, the UPS will retransfer.
OOC	Y	Output Overcurrent – UPS is overloaded.	Shut down excess equipment to reduce load.
VOOV	Y	Output Overvoltage – Output overvoltage condition occurred.	UPS is possibly faulty. Check the UPS operation conditions at time of fault. Not advisable to restart the UPS. Call Toshiba for service.
VOUV	Y	Output Undervoltage – Output undervoltage condition occurred.	UPS is possibly faulty. Check the UPS operation conditions at time of fault. Not advisable to restart the UPS. Call Toshiba for service.

16.4 System Warning Messages

Warning messages are generated when a noncritical abnormal operating condition occurs. The following table shows possible messages and their meaning.

When a Warning condition exists, the amber LED on the UPS display panel will flash for the duration of the Warning condition.

All warnings will clear after the appropriate action has been taken.

TABLE 16-3: UPS WARNING MESSAGES

Display	Re-corded	Meaning	Action
AOH	Y	Ambient Overheat – The unit is overheated.	Check to see if the ambient temperature is greater than 104 °F (40 °C) If so, turn on air conditioning and check the ventilation fan at the back of the unit for operation or obstructions. Otherwise, shut down the unit and call Toshiba for service.
ASYN	N	Asynchronous mode – Input and output frequency are different. Bypass is disabled.	No Action Needed.

Display	Re-corded	Meaning	Action
BDEPL	N	Battery Depleted – Battery not within specifications.	Call Toshiba for service.
BLFE	Y	Battery Lifetime End – Batteries at end of life.	Have batteries replaced immediately.
BLFN	Y	Battery Lifetime Near End – Batteries are nearing the end of their expected lifetime.	Call Toshiba for service.
BOH	Y	Battery Overheat – Battery not within specifications.	Call Toshiba for service.
BRPL	Y	Replace Battery – Battery at end of life expectancy.	Replace battery immediately.
BSDV	N	Battery Shutdown Voltage – Battery is discharged down to minimum level.	UPS will shut down. Secure critical loads until power can be restored.
BTSTFL	N	Battery Test Failed – Battery not within specifications.	Call Toshiba for service.
BYPOV	N	Bypass Overvoltage – Bypass voltage exceeds UPS specifications. (See NOTE, Page A-1 “Bypass Voltage”)	UPS in Bypass Mode: UPS turns off bypass power to the load until bypass power returns to normal. Check bypass power.
BYPUV	N	Bypass Undervoltage – Bypass voltage less than UPS specifications. (See NOTE, Page A-1 “Bypass Voltage”)	UPS in Bypass Mode: UPS turns off bypass power to the load until bypass power returns to normal. Check bypass power.
CALL	Y	Service Call Required – Inspection of the unit is advised.	Have inspection/service performed.
CHRG OV	Y	Charger Overvoltage – Battery Charger not within specifications.	Call Toshiba for service.
CLMT	N	Current Limit – UPS not within specifications.	Call Toshiba for service.
DCER	Y	Display Cable Error – Display cable is disconnected.	Connect the display cable.
DCANERR	N	Communication Error between Display and Main Controllers.	Call Toshiba for service.
EXTBC1	N	1. BC1 Battery String 1, 2, or 3 Disconnected 2. BC1 Over Temperature 3. BC1 Lost Communications with UPS	- Recover without power cycle - Must Manually Reset. - Reduce Load on BC, call factory Toshiba for Service - Call Toshiba for Service
EXTBC2	N	1. BC2 Battery String 1, 2, or 3 Disconnected 2. BC2 Over Temperature 3. BC2 Lost Communications with UPS	- Recover without power cycle - Must Manually Reset. - Reduce Load on BC, call Toshiba for Service - Call Toshiba for Service

Display	Re-corded	Meaning	Action
FBYPER	N	Bypass Frequency Error – Input frequency outside of UPS specifications.	UPS in Bypass Mode: UPS turns off bypass power to the load until bypass frequency returns to normal. Check bypass frequency.
FIER	N	Input Frequency Error – Input frequency outside of 45 – 65 Hz range.	UPS in Online Mode: UPS switches to BACKUP mode until Input Frequency returns to normal.
LB	N	Low Battery – The battery level has dropped low (about 90% or less) during operation. Continued operation in this mode will deplete battery and cause output shut down.	Immediately shut down the load equipment in an orderly fashion and then press the STOP key.
OL110	N	Overload – UPS is overloaded (110% and above) Unit will switch to bypass operation or shut down if no action is taken.	Shut down excess equipment to reduce load.
REYEERR	N	Communication Error between RemotEye and UPS.	Ensure RemotEye is connected to UPS. Call Toshiba for service.
RS232ERR	N	Communication Error at Service Port.	Call Toshiba for service.
REYEUER	N	Communication Error at LAN.	Call Toshiba for service.
VDCUVBT	N	DC Bus Undervoltage During Battery Test.	Call Toshiba for service.
VIOV	N	Input Overvoltage – Input voltage exceeds UPS specifications.	UPS in On-Line Mode: UPS switches to BACKUP mode until Input Voltage returns to normal. Check input power.
VIUV	N	Input Undervoltage – Input voltage less than UPS specifications.	UPS in On-Line Mode: UPS switches to BACKUP mode until Input Voltage returns to normal. Check input power.

16.5 System Mode Messages

A UPS Mode message is generated when the UPS changes operating mode. The following tables list the possible operating modes for the UPS.

TABLE 16-4: UPS WARNING MESSAGES

Display	Meaning
Backup	Backup – Power comes from other than input.
BattTest	Battery Test – Battery test in progress.
Bypass	Bypass – UPS is offline, power is being provided directly from UPS input.
On-Line	On-Line – Input converter and inverter are running (Double conversion mode).
Shutdown	Shutdown – No output, DC Bus is charged through Softstart Resistor.
Startup	Startup – UPS is starting up.

16.6 System Status Messages

A UPS Status message is generated when the UPS changes its status (e.g. from inverter to bypass mode). The table below shows the possible Status messages and their meaning.

TABLE 16-5: UPS SYSTEM STATUS MESSAGES

Display	Meaning	Action
BYP	Bypass mode – Power is supplied by UPS input.	No action needed.
CHRGERR	Charger Error – Charger overvoltage error.	Call Toshiba for service.
DLYST	Delay Start – UPS is counting down prior to startup.	No action needed.
EE1ST	EEPROM is loaded with default values.	No action needed.
EE2RAERR	EEPROM to RAM loading Error.	Call Toshiba for service.
EEUPERR	EEPROM updating Error.	Call Toshiba for service.
EPO	EPO circuit is active.	Reset EPO switch to start.
FIERRST	Frequency Input Error Start – Input frequency could not be detected and UPS starts up with default EEPROM setup.	Ensure correct input frequency is selected in UPS settings.
FLT	A fault has occurred.	See Fault records.
FWUPERR	Firmware Update Error.	Call Toshiba for service.
INIT	Initialization – UPS is initializing.	No action needed.
INV	Inverter mode.	Inverter is running (it can be On-Line, Battery Test, or Backup)
LANSD	UPS goes to Shutdown triggered from customer supplied LAN SD circuit.	Deactivate LAN shutdown signal to reset.
LB	Low Battery – The battery level has dropped low (about 90% or less) during operation. Continued operation in this mode will deplete battery and cause output shut down.	Immediately shut down the load equipment in an orderly fashion and then press the STOP key.
PFAIL	Input power failure.	No action needed.
RMTSD	Remote shutdown occurred.	Disconnect LAN signal to reset.
RO2EEERR	ROM to EE Loading Error.	Call Toshiba for service.
SYNC	Synchronous mode.	Input and output are synchronized.
TIMEDSD	UPS is counting down prior to shutdown.	Immediately shut down the load equipment in an orderly fashion and then press the STOP key.
WRN	A warning has occurred.	See Warning record.

17. Preventive Maintenance/Parts Replacement

17.1 Preventive Maintenance

Toshiba T1000 is designed to provide years of trouble-free operation requiring a minimum amount of preventive maintenance.

The best preventive measure that the UPS user can take is to keep the area around the unit, particularly the air inlet vents, clean and free of moisture and dust accumulations. If the atmosphere of the installation site is very dusty, use a vacuum cleaner to periodically remove dust accumulations around and from the unit.



CAUTION

Only a qualified Toshiba representative should be allowed to perform any routine maintenance or service on this equipment other than those preventive maintenance details which are described directly above this caution.

17.2 LCD Display Cleaning

The LCD display should be cleaned with a clean, damp cotton cloth to avoid scratching the coating.

17.3 Battery Replacement

The T1000 comes equipped with internal backup batteries packaged in three sets of 6 batteries per battery pack.

NOTICE

Ensure the T1000 battery packs are replaced with battery packs of the same part number. Failure to do so may cause unexpected loss of backup power.

17.4 Part Replacement

The following list shows recommended intervals for periodic replacement of certain UPS parts:

1. Electrolytic capacitor PC Board: Replace capacitor boards once every 5 years.
(The electrolytic aluminum capacitors are mounted on a PC Board)
2. Fuses: Replace once every 7 years.
3. Cooling fan: When operated in an ambient temperature of 86 °F (30 °C) to 104 °F (40 °C), replace every 3.5 years. When operated in an ambient temperature of less than 86 °F (30 °C), replace every 5 years.

NOTE: The cooling fans are not hot swappable. Remove all power from the UPS before replacing the cooling fans.

(Open the UPS main circuit breaker and disconnect external battery interface cable.)
4. Batteries: In order to maintain system reliability, the UPS batteries should be replaced on a regular schedule. To ensure reliable operation, all of the batteries should be replaced at the same time. Use the following chart for replacement:

UPS BATTERY REPLACEMENT

BATT AMB TEMP*	AVERAGE LIFETIME
68 – 77 °F (20 – 25 °C)	Approximately 5 yrs.
86 °F (30 °C)	Approximately 3.5 yrs.
95 °F (35 °C)	Approximately 2.5 yrs.
104 °F (40 °C)	Approximately 1.8 yrs.
113 °F (45 °C)	Approximately 1.25 yrs.

* Continual operation at ambient temperatures above 25 °C will degrade the battery life.

18. Shipping Weights/Dimensions

18.1 Unit and Shipping Weights

Unit	Part Number	Unit Weight ¹		Shipping Weight ¹	
		Pounds	Kilograms	Pounds	Kilograms
Power Module (Rack) 5.2kVA	T1P0A5200GXGR3L1	63	28.6	92	41.7
Power Module (Tower) 5.2kVA	T1P0A5200GXGL1	63	28.6	92	41.7
Power Module (Rack) 6kVA	T1P0A6000GXGR3	63	28.6	92	41.7
Power Module (Tower) 6kVA	T1P0A6000GXG	63	28.6	92	41.7
Battery Module (Rack)	T1B06000005R3	147	66.7	176	79.8
Battery Module (Tower)	T1B06000005	147	66.7	176	79.8
Battery Mod. w/ Panel Option (Rack) (Tower)	T1B06000005R3Px	149	67.7	178	80.8
	T1B06000005Px	149	67.7	178	80.8
Transformer Module (Rack)	T1X06000GA-N1-R3	76	34.5	105	47.6
Transformer Module (Tower)	T1X06000GA-N1	76	34.5	105	47.6

1. Subject to change without notice.

18.2 Shipping Dimensions

All modules are individually palletized. The module/pallet assembly measurement are shown in the table below:

Shipping Dimensions			
	Height	Width	Depth
Palletized Module (5.2 & 6 kVA)	16.5 in. (491 mm)	24 in. (610 mm)	34 in. (864 mm)
Module packaging (without pallet)	11 in. (279 mm)	23 in. (584 mm)	32.75 in. (832 mm)

This page intentionally left blank

Appendix A: Specifications

A.1 T1000 POWER MODULE - 6kVA

NOTE: Except for size, weight, and Part Number, the Rackmount and Tower specifications are the same.

T1000 6 KVA SPECIFICATIONS - POWER MODULE	
Parameter	Value
GENERAL	
Model No.	Tower T1P0A6000GXG Tower with Line Cord T1P0A6000GXGL1 Rackmount T1P0A6000GXGR3 Rackmount with Line Cord T1P0A6000GXGR3L1
Capacity Output	6 kVA
Topology	True Online, Double conversion, IGBT Power Factor Correction Input
INPUT	
Voltage (V)	Single Phase - 208/240 Vin +10% to -15% (L to L)* (Adjustable to +10/-10%, or +15/-20%; set on front panel) (*NOTE: Down to Vin -30% @ 70% Load)
Current (Nominal) (A)	25 A @ 240 V (30 A @ 208 V)
Current (Max) @ 208 V (A)	32 A
Current (Max) @ 240 V (A)	25 A (32 A @ 85% of 240 V)
Current (Min.) No-Load @ 240 V (A)	8 A (Typical)
Current, Peak Inrush (A)	20 A Peak (Typical)
Current Limit (%)	125%
Current THD (%)	< 5%
Frequency (Hz) [and range]	45-65 Hz auto sensing $\pm$ 3 Hz
Input Power Factor (PF) @ full load	Greater than 0.97
Startup Delay (sec)	Default: 0 sec (Range: 0 – 800 sec in 1 sec increments)
Ground leakage (max.) (mA)	5 mA (UPS only)
Internal AC Input Breaker Rating	50 A, 240 V
Surge Protection (kA or Category)	MOV 250 Joules on Input
BYPASS	
Voltage (V) (selectable)	Set by display panel : +10/-15% of nominal (default); +10/-10% of nominal +15/-20% of nominal <i>NOTE: The Display software cannot make floating point (decimal) calculations. There may be differences between the nominal and calculated BYPOV and BYPUV. Example: BYPOV set to 115%, at 208V that should be 239.2V. The decimal value .2 will be truncated (cut off) and the value 239V will be sent to the control board. This will be read back to the display as 114% (114.9% truncates to 114%).</i>
Bypass Overload @ 125% Load (min)	10 min.
Bypass Overload @ 1000% Load	1 cycle
Bypass Disable	Automatic (when Input and Output Voltage/Frequency are set to different values)
Automatic Retransfer (Max load % for Retransfer)	4 ms (1/4 cycle) at <105% Max Load

T1000 6 KVA SPECIFICATIONS - POWER MODULE	
Parameter	Value
Max. Automatic Retransfer Attempts	2
Online Transfer Time – Inverter to Bypass and Bypass to Inverter	Less than 4 ms
OUTPUT	
Voltage (V)	200 / 208 / 220 / 230 / 240 V (L-L) and Option with transformer for 120 V (L-N)
Voltage Regulation - Online Mode (%)	± 3%
Voltage Regulation - Battery Mode (%)	±3% Vrms for entire battery voltage range and 0 to 100% load
Wave Form	Sine wave, zero transfer time
Voltage Total Harmonic Distortion (Linear Full Load) (%)	Less than 3 % THD
Voltage Total Harmonic Distortion (Non-Linear Full Load) (%)	Less than 5 % THD
Output Voltage Adjustment (V)	±10 V in 1 V increments
Voltage Transient Response (%) @ 0%-100% Step Load Change	± 8 % max.
Voltage Transient Response (%) @ 100%-0%-100% Load Change	± 8 % max.
Voltage Transient Recovery with R Load (Recovery to 1% in x ms)	To +/- 1% of nominal voltage within 30 ms
Common-mode Noise (dB)	less than 0.5 Vrms
Current (A)	25 A (Current limited to 25 A regardless of selected output voltage)
Max Overload Current (continuous) (A)	25 A
Crest Factor	3.0 at full load
Leakage Current to Ground (mA)	5 mA
Inrush Current Protection	via Soft Start (Charge) Circuit
Frequency (Hz)	50 / 60 Hz auto sensing
Frequency Selectable (Converter)	Yes - 50/60 Hz
Frequency Regulation (%) Free Running Mode	± 0.25 Hz
Frequency Sync Range (Hz)	± 3 Hz selectable in 0.1 Hz increments (± 1 Hz default)
Slew Rate (Hz/sec)	± 3 Hz/sec selectable in 0.1 Hz/sec increments (± 1 Hz/sec default)
Output Power Factor (PF)	0.9 at rated voltage and current (1.0 allowed if output current ≤ 25 A and output power is ≤ 5400 W) (Min. 0.4 PF Lagging)
Inverter Overload Capacity (% for sec)	125% for 1 min., 150% for 10 sec.
Efficiency AC-DC-AC (240V) (%)	87% (Typical)
Efficiency AC-DC-AC (120V w/ Transformer Module (%)	84% (Typical)
Unloaded Power Consumption	479 W

T1000 6 KVA SPECIFICATIONS - POWER MODULE	
Parameter	Value
Short Circuit Protection	Electronic and Hardware Overload Protection
Cold Start (0-100% load)	Default Output Frequency 60 Hz
Battery General, External	
Acceptable Mfr.	Yuasa Taiwan only
Type	~9 AH/12 V Valve Regulated Lead Acid, Flame Retardant
	Access to batteries requires use of only Phillips head screwdriver
Voltage - Nominal (Vdc)	216 Vdc
Voltage - Minimum (Vdc)	170 Vdc
Voltage -Float (Vdc)	245 Vdc
Max Recharge Current - (Adc)	1.3 A
Recharge Time (Max.)	4 hours to 90% 24 hours to 100%
	Maintains proper float voltage per battery specification over a temperature range of 10 to 40 degree C (2.3 V/cell at 25 degree C with a temperature coefficient of minus 5 millivolts per degree C)
Max Discharge Current - (Adc)	40 Adc (Typical)
Battery Level @ Shutdown	1.67 VPC, $\pm$ 3% of battery voltage at FL with level automatically raised for lighter loads
Ripple Current (Max.) (% of Full Load Current)	15%
Battery Leakage to Ground (mA)	100 mA maximum
Battery Capacity Required at Full Load (W Battery)	6505 WB at nominal Bus Voltage (6826 WB at shutdown)
Battery Test (Interval per hr)	Automatic and Manual
Battery Low Alarm	~90% of full 216 V Battery Charge
Battery Protection	Fuse
Overvoltage Protection	2.50 VPC, $\pm$ 3% of battery voltage
Protection against Batteries Deep Discharge	Adjustable SDN (Shutdown) level
Backup Time @ Full Load (Typical)	1 Battery Module - 5 min. 2 battery Modules - 10 min. (Typical: 1 Battery Module - 8 min. 2 battery Modules - 16 min.)
Efficiency DC-AC (%)	85% (Typical)
BATTERY - INTERNAL	
Internal Back-up Time at Full Load (at 25 °C) (min)	5 min.
Type / Rating (Ah)	12 Vdc, ~9 Ahr
Number of Batteries	6 Batteries per tray, 3 trays per Battery Module
Replaceable Batteries	Yes
ENVIRONMENT	
Cooling	Forced Air
Operating Temperature (°F/°C)	0 - 40°C (32 - 104°F)

T1000 6 KVA SPECIFICATIONS - POWER MODULE	
Parameter	Value
Storage Temperature (°F/°C)	-20 - 40°C (-4 - 104°F)
Operating Humidity (%)	30-90% (Non-Condensing)
Altitude (ft./m)	3280 ft. (1000 m) above sea level Derate output 5% for each additional 3280 ft. (1000 m) elevation.
Acoustical Noise (dBA)	50 dB(A) maximum at 1 meter from Front Panel (Typical)
Location	Indoors, away from excessive heat, dust, and moisture.
Heat Rejection (BTU/Hour) @ 240 V	2753 BTU/Hr. (typical)
MECHANICAL	
Cable Access	Rear
Line Cord (Input) (Optional)	Option - Factory-installed 3-conductor #10 SO cord with 6-50P plug
Receptacles	Standard: Terminal Block with J-Box and one (1) L6-30R receptacle Option: Mount two (2) L6-30R receptacles
Weight lb./(kg)	63 lb. (28.6 kg)
Dimensions - Rackmount WxDxH in (mm)	w/o Side Supp. Tab: 16.73 in x 24.38 in x 5.22 in (425 mm x 619 mm x 133 mm) w/ Side Supp. Tab: 19.03 in x 24.38 in x 5.22 in (483 mm x 619 mm x 133 mm)
Dimensions - Tower WxDxH in (mm)	Standard: 5.22 in x 24.38 in x 16.73 in (133 mm x 619 mm x 425 mm) Caster Option: 5.22 in x 29.29 in x 17.48 in (133 mm x 744 mm x 444 mm)
Clearance - Rackmount (in/mm)	Front - 32 in., Rear - N/A in., Top/Bottom - N/A in., Sides N/A
Clearance - Tower (in/mm)	Front - 32 in., Rear - 4 in., Sides/Top - 4 in., Bottom N/A
Enclosure	Unit enclosure made from sheet metal meeting NEMA 1 and UL Type 1 Standard
Color	O'Brien Black
Emergency Power Off (EPO)	Back Panel (Remote Only)
Control Panel	T1000 Series Panel
MONITORING	
Operator Interface (Front Panel)	T1000 Series Panel
Dry Contacts Included	Accessible via DB9 receptacle on back of Power Module
USB	via mini-USB adapter
Optional - Intelligent Monitoring	RemotEye® Option card Slot (Network and RS-485)
ADDITIONAL FEATURES	
Optional - Line Cord	Option - Terminal Block with 3-conductor SO cord with L6-50P Plug
Receptacles	Standard: Terminal Block with J-Box and one (1) L6-30R receptacle Option: Mount two (2) L6-30R receptacles
External Connectors	EPO, USB, Remote Stop

T1000 6 KVA SPECIFICATIONS - POWER MODULE	
Parameter	Value
Rackmount Hardware (Standard)	All Rackmount modules come standard with the 4-Post Mounting Kit, P/N 92802.
Rail Kit (Optional)	Optional Rails Kits available with Rack-mount Models
Mounting Kits	(Each system configuration requires one of the following kits for each module)
Tower - 3 Module Systems	P/N 93178: One per system
Tower - Caster Kit (Optional)	P/N 92508: One per module
Rackmount - 2-Post fixed	P/N 92801: One per module
Rackmount - 4-Post fixed	P/N 92802: One per module (Included)
Rackmount - 2-Post w/ slides	P/N 90399: One per module
Rackmount - 4-Post w/ slides	P/N 92800: One per module
OTHER	
Warranty (yr.)	Three years on electronics, Two years full replacement on battery (See Toshiba warranty policy for full details.)
Certifications	UL 1778, FCC Class A Part 15,

1. Input/output figures rated for 240 volts unless otherwise stated. Output ratings given for 0.9PF are only valid when the input voltage is greater than 204 volts; otherwise, ratings given for 0.70PF are applicable.
2. Battery backup time may vary depending on the operating conditions and ambient temperature at the installation site.
3. An initial charge time of 24 hrs. is necessary to obtain proper battery performance level before unit is placed in operation.
4. If Vin is below the minimum Vin window, the UPS goes to Battery Mode. If the UPS is in Fault and Vin is below the minimum Vin window, the UPS goes to Bypass Mode

T1000 6KVA EFFICIENCY AT % OF FULL LOAD ¹					
(1.0 PF @ 240 V)	No Load	25%	50%	75%	100%
Efficiency (AC-AC)	(479 W)	78.5%	85.6%	87%	87%
Thermal Load (BTU/hr)	1634	1262	1550	2065	2753

1. Typical efficiency values. Individual results may vary.

T1000 BATTERY MODULE TYPICAL BACKUP TIME AT DIFFERENT LOADS										
Estimated* Backup time in minutes at % full load @ 0.9 PF										
# of T1B-6000xxx	10%	20%	30%	40%	50%	60%	70%	80%	90%	100%
1 Battery Module	>60	>60	42	28	20	16	12.5	10	8.5	5
2 Battery Modules	>60	>60	>60	>60	50	42	34	28	24	20

* Backup times are estimates only. Actual time will vary due to manufacturing variances, age of batteries, duty cycle, etc.

A.2 T1000 POWER MODULE - 5.2kVA

NOTE: Except for size, weight, and Part Number, the Rackmount and Tower specifications are the same.

T1000 5.2 KVA SPECIFICATIONS - POWER MODULE	
Parameter	Value
GENERAL	
Model No. Tower with Line Cord Rackmount with Line Cord:	T1P0A5200GXGL1 T1P0A5200GXGR3L1
Capacity Output	5.2 kVA
Topology	True Online, Double conversion, IGBT Power Factor Correction Input
INPUT	
Voltage (V)	Single Phase - 208/240 Vin +10% to -15% (L to L)* (Adjustable to +10/-10%, or +15/-20%; set on front panel) (*NOTE: Down to Vin -30% @ 70% Load)
Current (Nominal) (A)	21.6 A @ 240 V (26 A @ 208 V)
Current (Max) @ 208 V (A)	27.7 A
Current (Max) @ 240 V (A)	21.6 A (26 A @ 85% of 240 V)
Current (Min.) No-Load @ 240 V (A)	8 A (Typical)
Current, Peak Inrush (A)	20 A Peak (Typical)
Current Limit (%)	125%
Current THD (%)	< 5%
Frequency (Hz) [and range]	45-65 Hz auto sensing $\pm$ 3 Hz
Input Power Factor (PF) @ full load	Greater than 0.97
Startup Delay (sec)	Default: 0 sec (Range: 0 – 800 sec in 1 sec increments)
Ground leakage (max.) (mA)	5 mA (UPS only)
Internal AC Input Breaker Rating	30 A, 240 V
Surge Protection (kA or Category)	MOV 250 Joules on Input
BYPASS	
Voltage (V) (selectable)	Set by display panel : +10/-15% of nominal (default); +10/-10% of nominal +15/-20% of nominal <i>NOTE: The Display software cannot make floating point (decimal) calculations. There may be differences between the nominal and calculated BYPOV and BYPUV. Example: BYPOV set to 115%, at 208V that should be 239.2V. The decimal value .2 will be truncated (cut off) and the value 239V will be sent to the control board. This will be read back to the display as 114% (114.9% truncates to 114%).</i>
Bypass Overload @ 125% Load (min)	10 min.
Bypass Overload @ 1000% Load	1 cycle
Bypass Disable	Automatic (when Input and Output Voltage/Frequency are set to different values)
Automatic Retransfer (Max load % for Retransfer)	4 ms (1/4 cycle) at <105% Max Load
Max. Automatic Retransfer Attempts	2
Online Transfer Time – Inverter to Bypass and Bypass to Inverter	Less than 4 ms

T1000 5.2 KVA SPECIFICATIONS - POWER MODULE	
Parameter	Value
OUTPUT	
Voltage (V)	200 / 208 / 220 / 230 / 240 V (L-L) and Option with transformer for 120 V (L-N)
Voltage Regulation - Online Mode (%)	± 3%
Voltage Regulation - Battery Mode (%)	±3% Vrms for entire battery voltage range and 0 to 100% load
Wave Form	Sine wave, zero transfer time
Voltage Total Harmonic Distortion (Linear Full Load) (%)	Less than 3 % THD
Voltage Total Harmonic Distortion (Non-Linear Full Load) (%)	Less than 5 % THD
Output Voltage Adjustment (V)	±10 V in 1 V increments
Voltage Transient Response (%) @ 0%-100% Step Load Change	± 8 % max.
Voltage Transient Response (%) @ 100%-0%-100% Load Change	± 8 % max.
Voltage Transient Recovery with R Load (Recovery to 1% in x ms)	To +/- 1% of nominal voltage within 30 ms
Common-mode Noise (dB)	less than 0.5 Vrms
Current (A)	21.67 A (Current limited to 21.67A regardless of selected output voltage)
Max Overload Current (continuous) (A)	21.6 A
Crest Factor	3.0 at full load
Leakage Current to Ground (mA)	5 mA
Inrush Current Protection	via Soft Start (Charge) Circuit
Frequency (Hz)	50 / 60 Hz auto sensing
Frequency Selectable (Converter)	Yes - 50/60 Hz
Frequency Regulation (%) Free Running Mode	± 0.25 Hz
Frequency Sync Range (Hz)	± 3 Hz selectable in 0.1 Hz increments (± 1 Hz default)
Slew Rate (Hz/sec)	± 3 Hz/sec selectable in 0.1 Hz/sec increments (± 1 Hz/sec default)
Output Power Factor (PF)	0.9 at rated voltage and current (1.0 allowed if output current ≤ 21.67 A and output power is ≤ 4507 W) (Min. 0.4 PF Lagging)
Inverter Overload Capacity (% for sec)	125% for 1 min., 150% for 10 sec.
Efficiency AC-DC-AC (240V) (%)	87% (Typical)
Efficiency AC-DC-AC (120V w/ Transformer Module) (%)	84% (Typical)
Unloaded Power Consumption	479 W
Short Circuit Protection	Electronic and Hardware Overload Protection
Cold Start (0-100% load)	Default Output Frequency 60 Hz

T1000 5.2 KVA SPECIFICATIONS - POWER MODULE	
Parameter	Value
Battery General, External	
Acceptable Mfgr.	Yuasa Taiwan only
Type	~9 AH/12 V Valve Regulated Lead Acid, Flame Retardant
	Access to batteries requires use of only Phillips head screwdriver
Voltage - Nominal (Vdc)	216 Vdc
Voltage - Minimum (Vdc)	170 Vdc
Voltage -Float (Vdc)	245 Vdc
Max Recharge Current - (Adc)	1.3 A
Recharge Time (Max.)	4 hours to 90% 24 hours to 100%
	Maintains proper float voltage per battery specification over a temperature range of 10 to 40 degree C (2.3 V/cell at 25 degree C with a temperature coefficient of minus 5 millivolts per degree C)
Max Discharge Current - (Adc)	34.6 Adc (Typical)
Battery Level @ Shutdown	1.67 VPC, $\pm$ 3% of battery voltage at FL with level automatically raised for lighter loads
Ripple Current (Max.) (% of Full Load Current)	15%
Battery Leakage to Ground (mA)	100 mA maximum
Battery Capacity Required at Full Load (W Battery)	5637 WB at nominal Bus Voltage (5916 WB at shutdown)
Battery Test (Interval per hr)	Automatic and Manual
Battery Low Alarm	~90% of full 216 V Battery Charge
Battery Protection	Fuse
Overvoltage Protection	2.50 VPC, $\pm$ 3% of battery voltage
Protection against Batteries Deep Discharge	Adjustable SDN (Shutdown) level
Backup Time @ Full Load (Typical)	1 Battery Module - 5 min. 2 battery Modules - 10 min. (Typical: 1 Battery Module - 8 min. 2 battery Modules - 16 min.)
Efficiency DC-AC (%)	85% (Typical)
BATTERY - INTERNAL	
Internal Back-up Time at Full Load (at 25 °C) (min)	5 min.
Type / Rating (Ah)	12 Vdc, ~9 Ahr
Number of Batteries	6 Batteries per tray, 3 trays per Battery Module
Replaceable Batteries	Yes
ENVIRONMENT	
Cooling	Forced Air
Operating Temperature (°F/°C)	0 - 40°C (32 - 104°F)
Storage Temperature (°F/°C)	-20 - 40°C (-4 - 104°F)
Operating Humidity (%)	30-90% (Non-Condensing)

T1000 5.2 KVA SPECIFICATIONS - POWER MODULE	
Parameter	Value
Altitude (ft./m)	3280 ft. (1000 m) above sea level Derate output 5% for each additional 3280 ft. (1000 m) elevation.
Acoustical Noise (dBA)	50 dB(A) maximum at 1 meter from Front Panel (Typical)
Location	Indoors, away from excessive heat, dust, and moisture.
Heat Rejection (BTU/Hour) @ 240 V	2753 BTU/Hr. (typical)
MECHANICAL	
Cable Access	Rear
Line Cord (Input)	Factory-installed 3-conductor #10 AWG SO cord with L6-30P plug
Receptacles	Standard: Terminal Block with J-Box and one (1) L6-30R receptacle Option: Mount two (2) L6-30R receptacles
Weight lb./(kg)	63 lb. (28.6 kg)
Dimensions - Rackmount WxDxH in (mm)	w/o Side Supp. Tab: 16.73 in x 24.38 in x 5.22 in (425 mm x 619 mm x 133 mm) w/ Side Supp. Tab: 19.03 in x 24.38 in x 5.22 in (483 mm x 619 mm x 133 mm)
Dimensions - Tower WxDxH in (mm)	Standard: 5.22 in x 24.38 in x 16.73 in (133 mm x 619 mm x 425 mm) Caster Option: 5.22 in x 29.29 in x 17.48 in (133 mm x 744 mm x 444 mm)
Clearance - Rackmount (in/mm)	Front - 32 in., Rear - N/A in., Top/Bottom - N/A in., Sides N/A
Clearance - Tower (in/mm)	Front - 32 in., Rear - 4 in., Sides/Top - 4 in., Bottom N/A
Enclosure	Unit enclosure made from sheet metal meeting NEMA 1 and UL Type 1 Standard
Color	O'Brien Black
Emergency Power Off (EPO)	Back Panel (Remote Only)
Control Panel	T1000 Series Panel
MONITORING	
Operator Interface (Front Panel)	T1000 Series Panel
Dry Contacts Included	Accessible via DB9 receptacle on back of Power Module
USB	via mini-USB adapter
Optional - Intelligent Monitoring	RemotEye® Option card Slot (Network and RS-485)
ADDITIONAL FEATURES	
Receptacles	Standard: Terminal Block with J-Box and one (1) L6-30R receptacle Option: Mount two (2) L6-30R receptacles
External Connectors	EPO, USB, Remote Stop
Rackmount Hardware (Standard)	All Rackmount modules come standard with the 4-Post Mounting Kit, P/N 92802.
Rail Kit (Optional)	Optional Rails Kits available with Rack-mount Models
Mounting Kits	(Each system configuration requires one of the following kits for each module)

T1000 5.2 KVA SPECIFICATIONS - POWER MODULE	
Parameter	Value
Tower - 3 Module Systems	P/N 93178: One per system
Tower - Caster Kit (Optional)	P/N 92508: One per module
Rackmount - 2-Post fixed	P/N 92801: One per module
Rackmount - 4-Post fixed	P/N 92802: One per module (Included)
Rackmount - 2-Post w/ slides	P/N 90399: One per module
Rackmount - 4-Post w/ slides	P/N 92800: One per module
OTHER	
Warranty (yr.)	Three years on electronics, Two years full replacement on battery (See Toshiba warranty policy for full details.)
Certifications	UL 1778, FCC Class A Part 15,

1. Input/output figures rated for 240 volts unless otherwise stated. Output ratings given for 0.9PF are only valid when the input voltage is greater than 204 volts; otherwise, ratings given for 0.70PF are applicable.
2. Battery backup time may vary depending on the operating conditions and ambient temperature at the installation site.
3. An initial charge time of 24 hrs. is necessary to obtain proper battery performance level before unit is placed in operation.
4. If Vin is below the minimum Vin window, the UPS goes to Battery Mode. If the UPS is in Fault and Vin is below the minimum Vin window, the UPS goes to Bypass Mode

T1000 6KVA EFFICIENCY AT % OF FULL LOAD ¹					
(1.0 PF @ 240 V)	No Load	25%	50%	75%	100%
Efficiency (AC-AC)	(479 W)	78.5%	85.6%	87%	87%
Thermal Load (BTU/hr)	1634	1262	1550	2065	2753

1. Typical efficiency values. Individual results may vary.

T1000 BATTERY MODULE TYPICAL BACKUP TIME AT DIFFERENT LOADS										
Estimated* Backup time in minutes at % 6kVA @ 0.9 PF										
# of T1B-6000xxx	10%	20%	30%	40%	50%	60%	70%	80%	90%	100%
1 Battery Module	>60	>60	42	28	20	16	12.5	10	8.5	5
2 Battery Modules	>60	>60	>60	>60	50	42	34	28	24	20

* Backup times are estimates only. Actual time will vary due to manufacturing variances, age of batteries, duty cycle, etc.

A.3 T1000 BATTERY MODULE

Compatible with both the 5.2kVA and 6kVA Power Modules.

T1000 BATTERY MODULE SPECIFICATIONS	
Parameter	Value
GENERAL	
Model Number: Rackmount	T1B06000005R3
w/ P1 Receptacle Panel	T1B06000005R3P1 (4 x IEC C13 & 4 x IEC C19)
w/ P2 Receptacle Panel	T1B06000005R3P2 (2 x NEMA L6-20R and 1 x NEMA L6-30R)
Tower	T1B060000005
w/ P1 Receptacle Panel	T1B06000005P1 (4 x IEC C13 & 4 x IEC C19)
w/ P2 Receptacle Panel	T1B06000005P2 (2 x NEMA L6-20R and 1 x NEMA L6-30R)
DC Output Voltage (V)	216 VDC
Discharge Current (Nominal) (A)	30 A
Discharge Current (Max.) (A)	40 A
BATTERY - INTERNAL	
Internal Back-up Time at Full Load (at 25 °C) (min.)	5 min.
Type / Rating (Ah)	YUASA REW45-12FR / 8 Ah or YUASA NPX-L35/250FR / 9 Ah
Number of Batteries	18 (6 batteries per tray, 3 trays per Battery Module)
Number of Strings	1
Max. Recharge (A)	1 A (Typical)
MECHANICAL	
Cable Access	Rear
Line Cord (Input)	Dual Anderson receptacles
Output Receptacle Panels (Optional) (Receptacle and Rating)	Optional Output Receptacle Panel: 91425: 4 ea. C-13 (250 V, 10 A) & 4 ea. C-19 (250 V, 15 A) 91427: 2 ea. L6-20R (250 V, 20 A) & 1 ea. L6-30R (250 V, 30 A)
Output Receptacle Panels (Optional) (Receptacle Fusing)	91425: C-13 2 x (250 V, 10 A) & C-19 2 x (250 V, 15 A) 91427: L6-20R 1 x (250 V, 20 A) & L6-30R 1 x (250 V, 30 A)
Weight lb./ (kg)	147 lb. (66.7 kg)
Dimensions - Rackmount WxDxH in (mm)	w/o Side Supp. Tab: 16.73 in x 24.38 in x 5.22 in (425 mm x 619 mm x 133 mm) w/ Side Supp. Tab: 19.03 in x 24.38 in x 5.22 in (483 mm x 619 mm x 133 mm)
Dimensions - Tower WxDxH in (mm)	Standard: 5.22 in x x 24.38 in x 16.73 in (133 mm x 619 mm x 425 mm) Caster Option: 5.22 in x 29.29 in x 17.48 in (133 mm x 744 mm x 4445 mm)
Clearance - Rackmount (in/mm)	Front - 32 in, Rear - N/A in, Top/Bottom - 0 in., Sides N/A
Clearance - Tower (in/mm)	Front - 32 in, Rear - 4 in, Sides/Top - 0 in., Bottom N/A
Enclosure	Enclosure of unit made from sheet metal, meets NEMA 1 and UL Type 1 Standard
Construction	Unit enclosure made from sheet metal meeting NEMA 1 and UL Type 1 Standard

A.4 T1000 TRANSFORMER MODULE

Compatible with both the 5.2kVA and 6kVA Power Modules.

T1000 TRANSFORMER MODULE SPECIFICATIONS		
Parameter		Value
GENERAL		
Model Number:	Rackmount Tower	T1X06000GA-N1-R3 T1X06000GA-N1
Capacity Output		6kVA
Topology		applies an autotransformer to Power Module output
INPUT		
Voltage (V)		Single Phase - Either 240 V or 208 V (L to L, or L to N)
Current (Nominal) (A)		25 A
Current (Max) (A)		26 A
OUTPUT		
Voltage (V)		Single Phase - 120 Vout (L to L)
Current (Nominal) (A)		50 A
Current (Max) (A)		Fused to 20 A max to any one receptacle, 50 A total across all four receptacles <i>(Note: North American plugs with 2 vertical blades are limited to 15 A max, while plugs with one vertical and one horizontal blade are limited to 20A)</i>
MECHANICAL		
Cable Access		Rear
Input		Anderson connectors from Power Module
Receptacles		4 x 5-20R Duplex Output Receptacles
Weight lb/(kg)		76 lb. (34.5 kg)
Dimensions - Rackmount WxDxH in (mm)		w/o Side Supp. Tab: 16.73 in x 24.38 in x 5.22 in (425 mm x 619 mm x 133 mm) w/ Side Supp. Tab: 19.03 in x 24.38 in x 5.22 in (483 mm x 619 mm x 133 mm)
Dimensions - Tower WxDxH in (mm)		Standard: 5.22 in x x 24.38 in x 16.73 in (133 mm x 619 mm x 425 mm) Caster Option: 5.22 in x 29.29 in x 17.48 in (133 mm x 744 mm x 4445 mm)
Clearance - Rackmount (in/mm)		Front - 32 in., Rear - N/A in., Top/Bottom - 0 in., Sides N/A
Clearance - Tower (in/mm)		Front - 32 in., Rear - 4 in., Sides/Top - 0 in., Bottom N/A
Enclosure		Enclosure of unit made from sheet metal, meets NEMA 1 and UL Type 1 Standard
Construction		Unit enclosure made from sheet metal meeting NEMA 1 and UL Type 1 Standard

Appendix B: T1000 Menu Table

* - Changing parameter requires restarting Unit.

TOP MENU	SUB MENU	SUB-MENU PARAMETER	PARAMETER RANGE & FORMAT
On-Line STATUS	Input Freq., Out Freq., and Menu		
MENU			
Quick Config	** QUICK CONFIG **		
		Rated Vin	208/240 V
		Rated Vout	200, 208, 220, 230, 240 (User selectable)
		Vout Adjust	-10 to +10 V, in 1 V steps
		Batt Ins Date	mm/dd/yyyy
		UPS Date	Ddd mm/dd/yyyy (Mon 01/13/2013)
		UPS Time	hh:mm AM (or PM)
		En Batt Test*	Enable/Disable
Monitor	** MONITOR **		
	> Identification	Manufacturer	TOSHIBA
		Typeform*	e.g. – UH3B2060C6
		Serial No.	nnnnnnnn (e.g. - 080112345)
		Main Fware Ver	Main Firmware Version
		Main BSector Ver	e.g. – UH3MSV00001
		Main BLoader Ver	e.g. – UH3MBL0100
		EEPROM Ver	e.g. – JB0123456789
		System Name	e.g. – POD2

* - Changing parameter requires restarting Unit.

TOP MENU	SUB MENU	SUB-MENU PARAMETER	PARAMETER RANGE & FORMAT
Monitor (Cont.)	>Identification (Cont.)	Attach Devices	NONE or
		Install Date	yyyymmdd
	>Input	Input Config	1 Phase/240V-60Hz (e.g.)
		Input Voltage	nnnV
		Input Current	nn.nA
		Input Frequency	nn.nHz
		Input Power(W)	nnnnW
		Input Power(VA)	nnnnVA
		Rated Iin	5.2 kVA – 22.5A 6kVA – 26.0 A
		Input Voltage(%)	nnn%
		Input Current(%)	nnn%
		Rated InPower(W)	5.2 kVA – 5200W 6kVA – 6000W
	>Output	Output Config	1 Phase/230V-60Hz (e.g.)
		Output Voltage	nnnV
		Output Current	nn.nA
		Output Frequency	nn.nHz
		Output Power(W)	nnnnW
		Output Power(VA)	nnnnVA
		Output Load(%)	nnn%
		Rated Pout (W)	5.2 kVA – 4680W 6 kVA – 5400W

* - Changing parameter requires restarting Unit.

TOP MENU	SUB MENU	SUB-MENU PARAMETER	PARAMETER RANGE & FORMAT
		Rated Pout (VA)	5.2 kVA – 5200VA 6 kVA – 6000VA
		Rated PF	0.9
Monitor (Cont.)	>Bypass	Bypass Config	1 Phase/240V-60Hz (e.g.)
		Bypass Voltage	nnnV
		Bypass Current	nn.nA
		Bypass Frequency	nn.nHz
		Bypass Power(VA)	nnnnVA
	>Battery	Battery Voltage	nnnVdc
		Discharge Current	nn.nAdc
		Battery Capacity	nnn% (Percent of total available battery energy)
		Battery Runtime	nnSec (Range 0 - 65535)
		Charger Status	Normal / Preventative / Stop
		Total Discharges	range: 0 - 232
		Batt Sdown Level	79% of nominal 216 V full Batt. Charge
		Batt Ins Date	mm/dd/yyyy
		Low Batt Level	90% of nominal 216 V full Batt. Charge
	>Status Config & Ctl	System(CTL) Temp	nnC (°C)
		Battery Temp	nnC (°C)
		Current State	Shutdown / Online / Backup / Batt Test / Bypass / Startup

* - Changing parameter requires restarting Unit.

TOP MENU	SUB MENU	SUB-MENU PARAMETER	PARAMETER RANGE & FORMAT
		EPO Status	Open / Closed
		Inter Comm Status	Normal / Unknown / Disable / Error
		Batt Test Cond	“Ready for Test” or “Batt Test Prohibited”
Settings	** SETTING **		
	>Input	Rated Vin	208, 240
	>Output	Rated Vout*	200, 208, 220, 230, 240
		Rated Iout	5.52 kVA – 21.6 A 6 kVA – 25 A /
		Vout Adjust	-10 to +10 V, in 1 V steps
	>Bypass	BypUV Det Lvl	Range: 75% to 95%
		BypOV Det Lvl	Range: 105% to 118%
	>Battery	Batt Life Remain	32547Hr (Nominal remaining life based on battery life warranty)
		Rated Ahr	9 Ahr
		No Batt (Series)	nn (e.g. – 18 in one Battery Module)
		No Batt(Paral)	n (e.g. – 1 in one Battery Module)
		Batt Ins Date	mm/dd/yyyy
	>Status Config & Ctl	Requested State	(On-Line / Bypass / Shutdown / Batt Test)
		Faults	0X00000000
		Warnings	0X00000000

* - Changing parameter requires restarting Unit.

TOP MENU	SUB MENU	SUB-MENU PARAMETER	PARAMETER RANGE & FORMAT
		UPS Status (Comm)	0X00000000
		En CVCF*	Enable/Disable Frequency Conversion firmware
		CVCF Frequency*	50.0Hz/60.0Hz
		UPS Date	Ddd mm/dd/yyyy
		UPS Time	hh:mm AM (or PM)
Settings (Cont.)	>Status Config & Ctl (Cont.)	En Startup Delay*	Enable/Disable
		Startup Mode*	On-line/Shutdown/Bypass
		Startup Timer*	nnnSec (Range: 0 - 800)
		Mode of Rmt Sdown	Bypass / Shutdown
		En Batt Test Sup*	Enable/Disable
		En Batt Test*	Enable/Disable
		Batt Test Freq	Monthly/Weekly/Daily
		Service Port Mode	Protocol (Default) /Terminal (Factory only)
		En Restart	Enable/Disable
		Restart Delay	10 Sec (range 0-800 sec)
		En AutoXfer	Enable/Disable
		AutoXfer Window	3sec (Range- 0-600 sec)
		Restart Mode*	On-line/Bypass/Shutdown
	>History	System Op Time	nnnnnnSec (Up to 10 digits)
		Inverter Op Time	nnnnnnSec (Up to 10 digits)
		Backup Op Time	nnnnnnSec (Up to 10 digits)
		UPS Lifetime	nnnnnHr (Up to 10 digits)

* - Changing parameter requires restarting Unit.

TOP MENU	SUB MENU	SUB-MENU PARAMETER	PARAMETER RANGE & FORMAT
		Max System Temp	nnC (°C)
		Max Battery Temp	nnC (°C)
		Total VIUVs	nnnn (Up to 10 digits)
		Total OLS	nnnn (Up to 10 digits)
		Total Backups	nnnn (Up to 10 digits)
Settings (Cont.)	>History (Cont.)	Total Faults	nnnn (Up to 10 digits)
		Total Mode Change	nnnn (Up to 10 digits)
		Total Warnings	nnnn (Up to 10 digits)
		Total Sys Change	nnnn (Up to 10 digits)
Settings (Cont.)	>Display & Ext Comm	DFW Ver	Display Firmware Version
		RMTI Ins Dat	yyyymmdd
		RMTI Version	RemotEye version
		RMTI IP	nnn.nnn.nnn.nnn
		RMTI Network Mask	nnn.nnn.nnn.nnn
		RMTI Gateway IP	nnn.nnn.nnn.nnn
		RMTI Status	Uninstalled or Installed
		RMTI Netlink	Link Down / Link Up / Unknown
Records	** RECORDS **		
	>Fault		Rec No. nn (1 to 32)
	>Warning		Rec No. nn (1 to 32)
	>Backup		Rec No. nn (1 to 32)
	>Operation		Rec No. nn (1 to 32)

* - Changing parameter requires restarting Unit.

Appendix C: T1000 Dimensional Drawings




FIGURE C-1: T1000 POWER MODULE - OVERVIEW




FIGURE C-2: T1000 POWER MODULE - FRONT




FIGURE C-3: T1000 POWER MODULE - REAR




FIGURE C-4: T1000 POWER MODULE - PCB LOCATIONS




FIGURE C-5: T1000 BATTERY MODULE - OVERVIEW




FIGURE C-6: T1000 BATTERY MODULE - FRONT




FIGURE C-7: T1000 BATTERY MODULE - REAR




FIGURE C-8: T1000 BATTERY MODULE - INTERNAL LAYOUT




FIGURE C-9: T1000 TRANSFORMER MODULE - OVERVIEW





FIGURE C-10: T1000 TRANSFORMER MODULE - FRONT

OUTPUT PANEL 8X 5-20R
91426



REAR
VIEW

TOLERANCE
XX TO ±.05
XXX TO ±.005

REV: 0

JXXX-110-2005		DRAWN BY: JEE		DATE Apr-16-14	THIS MATERIAL IS THE EXCLUSIVE PROPERTY OF TOSHIBA INTERNATIONAL CORPORATION AND SHALL NOT BE REPRODUCED, USED OR DISCLOSED TO OTHERS UNLESS PRIOR WRITTEN AUTHORIZATION IS OBTAINED.	TITLE: TRANSFORMER MODULE T1000 SERIES UPS	SCALE 0.500	ORDER NO.
		CHECKED BY: ZIR		DATE May-07-15				
		APPROVED BY: WLM		DATE May-08-15				
					TOSHIBA INTERNATIONAL CORPORATION 13131 WEST LITTLE YORK ROAD, HOUSTON, TX, 77061, U.S.A.			
					DRAWING NO. 6XV1_0M_TRANSFORMER_MODULE SA 3 DF 4			

FIGURE C-11: T1000 TRANSFORMER MODULE - REAR




FIGURE C-12: T1000 TRANSFORMER MODULE - INTERNAL LAYOUT

Appendix D: T1000 Packing Lists and Kit Contents

The T1000 can be ordered in many different configurations. Use the Part Number on your unit(s) to check against the packing lists below. Notify your vendor immediately of any variances.

TABLE D-1: T1000 PACKAGE CONTENTS

UPS Module	Manual Pack	Interconnect Cables (see D.2.5)	Mounting Kit
Power Module (5.2 kVA)			
T1P0A5200GXGL1	91075	(None)	Tower Cap: 1 per System 2 Modules - P/N 93177 3 Modules - P/N 93178
T1P0A5200GXGR3L1	91075	(None)	1 of installation Kit 92802.
Power Module (6 kVA)			
T1P0A6000GXG	91075	(None)	Tower Cap: 1 per System 2 Modules - P/N 93177 3 Modules - P/N 93178
T1P0A6000GXGR3	91075	(None)	1 of installation Kit 92802.
Battery Module 1			
T1B06000005	91075	1 ea. 92855 - Batt. DC to Pwr Module DC	(See Tower Pwr Module)
T1B06000005P1	91075	1 ea. 92855 - Batt. DC to Pwr Module DC 1 ea. 92858 - Pwr Module L6-30 Out to Batt. Panel Anderson Input (240V)	
T1B06000005P2	91075	1 ea. 92855 - Batt. DC to Pwr Module DC 1 ea. 92858 - Pwr Module L6-30 Out to Batt. Panel Anderson Input (240V)	
T1B06000005R3	91075	1 ea. 92855 - Batt. DC to Pwr Module DC	1 of installation Kit 92802.
T1B06000005R3P1	91075	1 ea. 92855 - Batt. DC to Pwr Module DC 1 ea. 92858 - Pwr Module L6-30 Out to Batt. Panel Anderson Input (240V)	
T1B06000005R3P2	91075	1 ea. 92855 - Batt. DC to Pwr Module DC 1 ea. 92858 - Pwr Module L6-30 Out to Batt. Panel Anderson Input (240V)	
Battery Module 2			
T1B06000005	91075	1 ea. 92855 - Batt. Module 1 DC to Batt Module 2 DC	(See Tower Pwr Module)
T1B06000005R3	91075	1 ea. 92855 - Batt. Module 1 DC to Batt Module 2 DC	1 of installation Kit 92802.
Transformer Module			
T1X06000GA-N1	91075	1 ea. 92858 - 240V Anderson to L6-30P 1 ea. 92883 - 208V Anderson to L6-30P	(See Tower Pwr Module)
T1X06000GA-N1-R3	91075	1 ea. 92858 - 240V Anderson to L6-30P 1 ea. 92883 - 208V Anderson to L6-30P	1 of installation Kit 92802.

Inter-Module Cabling Identification

- 92855 - Pwr Module "EXT. BATTERY" to BC1 CN12A- DC/Thermistor Connector
- 92858 - Power Module L6-30 Output to Batt. Module Receptacle Panel or Xfmr Module (240V tap)
- 92883 - Power Module L6-30 Output to Xfmr Module Input (208V tap)

Appendix E: T1000 Optional Installation Kit Instructions

The T1000 can be installed in several configurations with the aid of optional installation kits.

E.1 Optional 3-Module Tower Cap Kit - 93178

T1000 Series UPS Tower Cap Installation Instructions - 94037-000

An Optional Tower Cap Kit are available for 3-module T1000 tower systems. If the optional Caster Kits are to be used, the casters should be installed before the Tower Cap is installed.

1 Tower Cap Kit

The tower configuration modules are arranged side by side, and secured by a press-fit cap over the assembly.

2 Contents - Tower Cap Kit (1 Cap per UPS System)

- 1 ea.: T1000 Series UPS Tower Cap Installation Instructions - 94037
- 1 ea.: 93178 - Tower Cap for 3 module System

3 Install Tower Cap

NOTE: If optional Caster Kits, P/N 90508, are to be used, install them before installing the Tower Cap.

1. Unpack the T1000 modules and set them in the desired location with the faceplates at the top as shown below. (Figure 2-A)
2. Facing the front of the modules, arrange them left to right in the following order:
 - Transformer Module (if available)
 - Power Module
 - Battery Module with output panel(if available)
 - Second Battery Module without output panel (if available)
3. Locate the front of the Tower Cap. The front of the Cap has three tabs extending beyond the skirt line. See Figure 1.
4. Fit the Tower Cap over the T1000 Modules, beginning with the front and lower the bak end over the top back of the modules.
5. Press the T1000 Tower Cap over the tower modules (Figure 2-B).
6. TThe T1000 tower is ready for installing the interconnecting cables. See the T1000 Installation and Operation Manual - 91074.




FIGURE 1: TOWER CAP FRONT - DETAIL




FIGURE 2: INSTALL CAP ON THREE MODULE TOWER SYSTEM

E.2 Optional Tower Caster Kit - 90508

T1000 Series UPS Tower Caster Kit Installation Instructions - 94031-000

1. T1000 Tower Caster Kit

The tower configuration modules may be modified with an optional Caster Kit containing a pair of caster and leveling foot assemblies. Each module requires one Caster Kit.

2. Contents - T1000 Tower Caster Kit (90508)

- 1 ea.: Tower Caster Kit Installation Instructions - 94031
- 2 ea.: 91438 - Caster Bracket, Black
- 2 ea.: 91439 - Connector Plate, Black
- 2 ea.: Knob, Leveling, 1/4"-20
- 2 ea.: Leveling Feet, Female
- 4 ea.: Caster, 2x appliance, 5/16"-18
- 4 ea.: Nut Cap, 5/16"-18
- 4 ea.: Washer, Belville, 5/16
- 7 ea.: Screw PHP (Pan Head Phillips) 10-32 x 1/2

3. Caster Kit Installation

Unpack the T1000 modules and assemble and install the casters as follows.

CASTER ASSEMBLY

1. Insert each caster appliance's threaded shafts through the Caster Bracket. (Figure 1)
2. Place a 5/16" Belville Washer over each caster shaft, then screw on the 5/16"-18 nut cap. Tighten the nut cap but do not bottom out the washer.
3. Repeat Steps 1-2 for the second caster appliance.
4. Screw the leveling knob through the 1/4"-20 pinnut in the Caster Bracket. (Figure 1, Figure 2)
5. Press the Leveling Foot over the end of the leveling knob shaft. (Figure 2)
6. Repeat Steps 1-5 for the remaining Caster Bracket.




FIGURE 1 CASTER BRACKET




FIGURE 2 CASTER ASSEMBLY - DETAIL

4. CASTER INSTALLATION

1. Lay each module on it's side so that the display/Name panel is on the right side as you face the front of the module. Position the module so you're facing the bottom of the unit. (Figure 3)
2. Locate the three caster mounting holes on the left side, and four mounting holes on the right side of the module. (Figure 3)
3. Secure one caster assembly to the rear base of the module using three (3) 10-32 x 1/2 Philips Screws. (Figure 4)
4. Secure the remaining caster assembly to the front base of the module using four (4) 10-32 x 1/2 Philips Screws. (Figure 4)
5. Repeat steps 7-10 for each module in the system.



FIGURE 3: POSITION MODULE FOR CASTER INSTALLATION




FIGURE 4: ATTACH CASTER ASSEMBLIES

6. Set the module(s) upright on the casters.
7. Position the module(s) near their final installation location.

NOTE: The casters roll in a straight line, but do not swivel. To turn the module, slide the front or back end laterally to change direction.

8. Facing the front of the modules, arrange the modules left to right in the following order:
 - Transformer Module (if available)
 - Power Module
 - Battery Module with output panel(if available)
 - Second Battery Module without output panel (if available)

1. Align the units and place the Tower Cap on the system.
 - 2 module tower systems, see **T1000 Installation and Operation Manual - 91074**.
 - 3-4 module tower systems, see **T1000 Tower Cap Installation Instructions - 94037**.
2. Use the leveling feet to remove weight from the casters. (Figure 5)
3. The T1000 tower is ready for installing the interconnecting cables. See the **T1000 Installation and Operation Manual - 91074**.




FIGURE 5: USE LOAD LEVELERS TO STABILIZE TOWER ASSEMBLY

E.3 Optional T1000 2-Post Rack Fixed Installation Kit - 92801

T1000 Series UPS 2-Post Rack Fixed Kit Installation Instructions - 94035-000

1. Rackmount Fixed Installation - 2-Post

Use the 2-Post Fixed Rackmount Kit 92801 (1 kit per module) to mount a T1000 module in a 2-Post 19 inch rack.

2. Contents - Fixed 2-Post Rack Installation Kit (92801)

- 1 ea.: T1000 2-Post Rack Fixed Installation Kit Instructions - 94035
- 4 ea.: 92756 - Bracket, Fixed Mounting, 2-Post, Black
- 16 ea.: Cage Nut, 1/4"-20
- 16 ea.: Hex bolt, 1/4"-20 x 5/8"
- 16 ea.: Nut, Spin Lock, 1/4"-20 G5
- 12 ea.: Screw, PHP (Pan Head Phillips) 10-32 x 1/2" St Box
- 4 ea.: Screw, PHP 8-32 x 1/4" St Zi

3. Prepare the 2-Post Rack (for rack rails with square holes)

1. Each 2-Post Fixed Mounting Bracket has 6 rack mounting holes. Place the bracket over the Rack Rail at the lowest desired elevation for the system modules. Ensure all 6 bracket holes align with rack rail holes.
2. Clip one cage nut (Cage Nut, 1/4"-20) at the top hole location on the rack rail, then clip cage nuts on the rack rail in the 2nd, 5th, and 6th hole position on the rack rail.

NOTE: Ensure all bracket slots align with the rack rail mounting holes to establish the bottom unit elevation.

NOTE: If installing more than one T1000 module, begin with the lowest module first.

3. Repeat step 2 for the other three mounting bracket locations for the bottom module.
4. If more than one module is being installed for the T1000 system, install the next set of cage nuts from the other module's 4-Post Slide Kit three (3) Rack Units (5 1/4") above the first set of cage nuts (Figure 5). Repeat steps 2-3.
5. Repeat steps 2-4 until cage nuts for all the modules in the system have been clipped on the 2-Post rack.

4. Install the 2-Post Rack Fixed Brackets

1. Bolt the 2-Post Fixed Bracket assembly to the 2-Post Rack using four (4) 1/4"-20 x 5/8" bolts for each bracket. (Figure 1)
2. Hold one of the 2-Post Fixed Mounting Brackets, P/N 92756, against the 2-Post rack rail at the level of the lowest module to be installed, with the bracket folds to the inside of the 2-Post rack (Figure 1).
3. Each 2-Post Fixed Mounting bracket has 6 rack mounting holes. Slip the hex bolt through the top (first) hole through the rack mounting flange and secure it with the cage nut (square holes) or 1/4"-20 Spin Lock Nut (round holes).
4. Slip a bolt through each of the brackets 2nd, 5th, and 6th holes and secure each with the cage nut (square holes) or 1/4"-20 Spin Lock Nut (round holes).
5. Repeat Steps 2-4 for remaining three mounting brackets (Figure 2).
6. If more than one module is being installed for the T1000 system,




FIGURE 1: 2-POST FIXED BRACKET RACK MOUNTING

install the remaining mounting kits as described in steps 1-5 (Figure 3).




FIGURE 2: INSTALL REMAINING 2-POST FIXED BRACKETS



FIGURE 3: INSTALL REMAINING MODULE BRACKETS

4. Install the Module in the 2-Post Rack



CAUTION: Battery Modules weight 150 lb. (68 kg).
Use lifting aids and proper lifting techniques.

NOTE: The T1000 System modules must be arranged top-to-bottom in the following relative order:

- Transformer Module (if present)
- Power (UPS) Module
- Battery Module w/Output Panel (if present)
- Battery Panel w/o Output Panel (if present)

1. Follow the vertical arrangement of T1000 modules as indicated in the NOTE above. Secure the lowest module in the 2-Post rack to the bottom four brackets. (Figure 4)
 - Each Front Bracket: 2 x Phillips 10-32 x 1/2" in the center slots. (Figure 3)
 - Each Rear bracket: 1 x Phillips 10-32 x 1/2" in the center slots. and 2 x Phillips 8-32 x 1/4" screw each in the top and bottom slot, (Figure 4)
2. Repeat Step 7 for the remaining modules, working from bottom to top. (Figure 6)
3. Go to [T1000 Installation and Operation Manual](#), 91074, for cabling instructions.




FIGURE 4: MOUNT MODULE ON 2-POST FIXED BRACKETS



**FIGURE. 5: INSTALL FIRST
T1000 MODULE**



**FIGURE. 6: INSTALL REMAINING
T1000 MODULES**

E.4 Optional T1000 4-Post Rack Slide Installation Kit - 92800

T1000 Series UPS 4-Post Rack Slide Kit Installation Instructions- 94034-000


1. 4-Post Rack Slide Kit

Use the 4-Post Rack Slide Kit 92800 (1 kit per module) to mount a T1000 module with slides in a 19-inch, 4-Post rack. The slide assemblies are non-handed, and are provided with a lock-open feature and a quick disconnect for the Inner Slide Member. When the Inner Slide Member is disconnected, the E-Z Rail latch in the slide assembly locks the Middle Member in the fully open position until the Inner Member is reinstalled.

2. Contents - 4-Post Rack Slide Installation Kit (92800)

- 1 ea.: T1000 Series UPS 4-Post Rack Slide Kit Installation Instructions - 94034
- 2 ea.: Slide, 22 in., 370EZ-22
- 2 ea.: Bracket, Front Offset, SPO-538
- 2 ea.: Bracket, Rear Offset, SPO-552
- 8 ea.: Screw, FHP (Flat Head Phillips) 8-32 x 3/8 in.
- 8 ea.: Nut, serrated head, 8-32
- 8 ea.: Screw, PHP, (Pan Head Phillips) 8-32 x 1/4 in.
- 16 ea.: Cage Nut, 1/4"-20
- 16 ea.: Hex bolt, 1/4"-20 x 5/8" (with assembled washer)

3. Attach E-Z Rail to Module



No.	ITEM
1	Slide Rail Inner Member (EZ Rail)
2	Slide Rail Middle Member
3	Slide Rail Outer Member (Outer Rail Sleeve)
4	E-Z Rail Latch

FIGURE 2 SLIDE ASSEMBLY

1. Remove the EZ Rail (Slide Rail Inner Member), Figure 2-(1), from the Slide Rail Middle Member, Figure 2-(2), by pressing the E-Z Rail Latch and sliding the EZ Rail out of the Middle Member. Repeat for the second Slide Assembly.
2. Attach an EZ Rail to each side of the UPS module using 4 x Phillips 8-32 x 1/4". Orient the inner Slide Member so the rounded end is towards the rear of the module. (Figure 3)




FIGURE 3: INSTALL INNER SLIDE MEMBER ON LEFT AND RIGHT SIDES OF MODULE(S)

3. Repeat Steps 1-2 for all modules to be installed.

4. Attach Extender Brackets to Slide Assemblies

1. Ensure the Middle Slide Member, Figure 2-(2), is extended forward from the outer slide sleeve (outer slide member), Figure 2-(3).

Note: The Bracket to Slide Assy. fasteners are a screw secured with a serrated nut.

2. Attach the long bracket to the rear of the slide assembly with two #8-32 x 3/8 in. screws and serrated nuts (Figure 4). Insert the FHP screws from the inside out, so the nut is on the outside of the slide assembly.

Do not over tighten the fasteners until the bracket assemblies have been mounted on the 4-Post rack.

3. Repeat Step 2 for the second long bracket.
4. Attach the front (short) bracket to the front of the slide assembly with two (2) #8-32 x 3/8 in. screws and serrated nuts (Figure 4). Insert the screws through the access holes provided in the Middle Slide Member.

Do not over tighten the fasteners until the bracket assemblies have been mounted on the 4-Post rack.

5. Repeat step 4 for the second front bracket.




FIGURE 4: ATTACH EXTENDER BRACKETS TO SLIDE ASSEMBLY

5. Attach Slide Assemblies to 4-Post Rack

1. Remove the cage nuts from the Slide kit.
2. Clip one cage nut (Cage Nut, 1/4"-20) from the 92800 kit over each post's rack mounting hole at the desired elevation. The nut should be on the inside of the rack.

NOTE: Ensure all bracket slots align with the rack rail mounting holes to establish the bottom unit elevation.

NOTE: If installing more than one T1000 module, begin with the lowest module first.

3. Clip a second cage nut 1.75 in. above each cage nut installed in step 1 (Figure 5). The nut should be on the inside of the rack.
4. If more than one module is being installed for the T1000 system, install the next set of cage nuts from the other module's 4-Post Slide Kit three (3) Rack Units (5 1/4") above the first set of cage nuts (Figure 5). Repeat steps 2-3.
5. Repeat steps 2-4 until cage nuts for all the modules in the system have been clipped on the 4-Post rack.
6. Bolt the Side Rail/Bracket assembly to the 4-Post Rack using two 1/4"-20 x 5/8" hex bolts each on the front and back. Thread the hex bolt from the outside, thru the rack flange and into the cage nut.

Ensure the end with the short adapter bracket is to the front of the rack. (See Figure 6)




FIGURE 5 CAGE NUT INSTALLATION

7. Tighten the #8-32 screws used to assemble the Slide Assembly and Bracket Extenders in Section 4.
8. Repeat step 6-7 for the remaining Side Rail/Bracket assemblies. (Figure 7)

6. Install T1000 Modules in Rackmount Slides

CAUTION: *Battery Modules weight 150 lb. (68 kg). Use lifting aids and proper lifting techniques*



ie T1000 System modules must be arranged top-in the following relative order:

ransformer Module (if present)

- Power (UPS) Module
- Battery Module w/Output Panel (if present)
- Battery Panel w/o Output Panel (if present)

1. Lift the module intended for the bottom slide rail set, and slide the module's E-Z Rails into the extended Slide Middle Members.
2. Gently slide the module backward until the slides are fully retracted.
3. Repeat steps 1-2 for the module slide rail set immediately above the bottom one.
4. Continue until all modules have been installed on their slide rails.
5. Go to ***T1000 Installation and Operation Manual - 91074*** to continue installation and cabling of the T1000 System.




FIGURE 6: INSTALL SLIDE RAIL ASSEMBLIES IN 4-POST RACK



FIGURE 7: INSTALL REMAINING SLIDE RAIL ASSEMBLIES IN 4-POST RACK

E.5 Optional T1000 2-Post Rack Slide Installation Kit - 90400

T1000 Series UPS 2-Post Rack Slide Kit Installation Instructions- 94030-001

1. 2-Post Rack Slide Kit

Use the 2-Post Rack Slide Kit 90400 (1 kit per module) to mount a T1000 module with slides in a 19-inch, 2-Post rack. The slide assemblies are non-handed, and are provided with a lock-open feature and a quick disconnect for the Inner Slide Member. When the Inner Slide Member is disconnected, the E-Z Rail latch in the slide assembly locks the Middle Member in the fully open position until the Inner Member is reinstalled.

2. Contents - 2-Post Rack Slide Installation Kit (90400)

- 1 ea.: T1000 Series UPS 2-Post Rack Slide Kit Installation Instructions - 94030
- 2 ea.: Slide, 22 in., 370EZ-22
- 1 ea.: **BK-4-EZ 2-Post Rack Bracket Kit, containing:**
 - 4 ea.: 2-Post Rack Bracket JES P/N 2496052
 - 8 ea.: Screw, FHP (Flat Head Phillips) 8-32 x 3/8 in.
 - 8 ea.: Nut, serrated head, 8-32
- 8 ea.: Screw, PHP, (Pan Head Phillips) 8-32 x 1/4 in. (for mounting inner slide member)
- 16 ea.: Cage Nut, 1/4"-20
- 16 ea.: SEMS Hex bolt, 1/4"-20 x 5/8" (with assembled washer) for racks with 1/4"-20 tapped holes.
- 16 ea.: SEMS Hex bolt, 10-32 x 5/8" (with assembled washer) for racks with 10-32 tapped holes.

3. Attach E-Z Rail to Module




FIGURE 1 SLIDE ASSEMBLY

1. Remove the EZ Rail (Slide Rail Inner Member), Figure 1-(1), from the Slide Rail Middle Channel, Figure 1-(2), by pressing the E-Z Rail Latch, Figure 1-(4), and sliding the EZ Rail out of the Middle Channel. Repeat for the second Slide Assembly.




FIGURE 2: INSTALL INNER SLIDE MEMBER ON LEFT AND RIGHT SIDES OF MODULE(S)

2. Attach an EZ Rail to each side of the UPS module using 4 x Phillips 8-32 x 1/4". Orient the inner Slide Member so the rounded end is towards the rear of the module. (Figure 2)

3. Repeat Step 1-2 for all modules to be installed.

4. Attach 2-Post Adapter Brackets to 2-Post Rack




FIGURE 3: 2-POST SLIDE BRACKET (4 PER MODULE)




FIGURE 4: 2-POST SLIDE BRACKET INSTALLATION (USING CAGE NUTS. OTHER FASTENERS SIMILAR.)

*NOTE: If Rack Rail holes are threaded, use either the 1/4-20 or 10-32 bolts included in the Installation Kit. If Rack rails have square penetrations, follow instructions below.***

NOTE: If installing more than one T1000 module, begin with the lowest module first.

1. Remove the cage nuts from the Slide kit.
2. Hold one of the 2-Post mounting brackets, P/N 2496052, against the 2-Post mounting flange at the level of the lowest module to be installed, with the bracket flange, Figure 2, to the outside of the 2-Post rack (Figure 3).

NOTE: Ensure all bracket slots align with the rack rail mounting holes to establish the bottom unit elevation.

3. Each 2-Post Mounting bracket has four (4) rack mounting bolt holes (Figure 1). Slip the cage nut over the top (first) rack rail mounting hole. Repeat for the rail holes corresponding to the 2nd, 3rd, and 4th bracket bolt holes.
4. Attach the 2-Post Slide Bracket on the 2-Post Rack using four (4) PHP, (Pan Head Phillips) 8-32 x 1/4 in. screws (or appropriate fasteners).
5. Repeat Steps 2-3 for the remaining three mounting brackets (Figure 4).

6. If more than one module is being installed for the T1000 system, install the remaining mounting bracket kits as described in steps 1-5.

5. Attach Rail Assemblies to 2-Post Adapter Brackets

1. Orient the Outer Channel Body of the Slide Assembly so the open side is facing inwards, and the front is towards the rack front. Open and fully extend the slide inner channel from the outer channel.

NOTE: There are six (6) mounting holes available for use. The first two holes, Figure 5 - #1 and #2, are accessible through openings in the Inner Channel when the Inner Channel is fully extended. The Rear-most mounting hole (Figure 5 - #6) may be blocked by the 2-Post mounting bracket.

2. Bolt the Outer Channel Body (370ez-27-11), Figure 1-(3) to the Slide Mount Brackets. (4 places) (See Figure 5) Recommend using holes #1, #2, #4, and #5 in Figure 5.
3. Insert the screws through the Outer Channel Body and 2-Post Slide Bracket (Figure 6).
4. Secure the four FHP 8-32 x 3/8 in. screws with the 8-32 serrated head nuts from 90400 kit. The nuts screw on from the outside of the 2-Post Slide Bracket. (Figure 6)
5. Repeat steps 1-4 for the second slide assembly.




FIGURE 5: SLIDE OUTER CHANNEL MOUNTING HOLE LOCATIONS




FIGURE 6: ATTACH OUTER CHANNEL TO 2-POST SLIDE BRACKET (2 PER MODULE)

6. Repeat steps 1-5 for each module to be installed. (See Figure 7)


6. Install T1000 Modules in Rackmount Slides



CAUTION: *Battery Modules weight 150 lb. (68 kg). Use lifting aids and proper lifting techniques*

NOTE: The T1000 System modules must be arranged top-to-bottom in the following relative order:

- Transformer Module (if present)
 - Power (UPS) Module
 - Battery Module w/Output Panel (if present)
 - Battery Panel w/o Output Panel (if present)
1. Lift the module intended for the bottom slide rail set, and slide the module's E-Z Rails into the extended Slide Middle Member.
 2. Gently slide the module backward until the slides are fully retracted. **FIGURE 7: INSTALL MODULES** (Figure 7)
 3. Repeat steps 1-2 for the module slide rail set immediately above the bottom one.
 4. Continue until all modules have been installed on their slide rails.
 5. Go to ***T1000 Installation and Operation Manual - 91074*** to continue installation and cabling of the T1000 System.



Index

A

AC input mode 36

Application 35

Audible alarm 35, 52, 53

B

Backup mode 37, 38

Battery

 backup mode 37, 38

 backup time 37, 38, 39, A-5

 disposal 7

 low-voltage tolerances 39

 recharge tolerances 40

 recharging 40, 48

 replacement 5, 59

 voltage drop 35, 37, 38, 49

Bypass

 mode 36

C

Cable size 24

capacitors 59

Cold Start 47

 Cold Start switch 28

 Procedure 38

Common-mode noise 35

Communication interface 49

Cooling fan 59

D

Data. *See* Data Display Screens, Data Setting
 Screens

DB9 Connector

 male pinouts 49

Dimensional Data 60

Disposal 7

E

Emergency Power Off (EPO) function 24, 37

Environment 7

F

fan 53

Fault

 protection functions 53, 54

 signal 49

Frequency

 Warning 27

Front Panel layout 34

G

ground

 Importance of, 8

Grounding 9

H

humidity 7

I

Input Frequency

 warning 27

Input Voltage A-5

Inspection 7

Installation 10

 rackmount arrangement 20

 tower arrangement 12, 13

Installation Precautions 8

Interface

 communications 49, 50

L

labels, warning 3

Layout, Back Panel 22

 Battery Module 23

 Power Module 22

 Transformer Module 24

Layout, Front Panel 28

 Cold Start Button 28

 Display 28

Lifetime

 battery 59

 capacitors, Aluminum electrolytic 59

 fan, cooling 59

 fuses 59

Low Voltage Tolerance 39

M

MAIN tab 34

maximum ambient operating temperature 5

Mode

 AC Input 36

N

Normal input power supply 49

O

Operation modes. *See* Modes

output disconnect 5

Overvoltage

 DC 53

 output 52

P

Power Conditioning 35

Power factor

 output, rated load 39

Power failure signal 49

Precautions 27

Protection System 52

R

Recharge Time 40

RECORDS tab

 Fault messages 54

remote contacts interface 49

Remote Switch 24

Restrictions on UPS use 27

S

Safety instructions 1, 5

Shipping Weight 60

Shutdown voltage 39

Signal Function

 RS-232C 49

Signal Words 2

Size

 wire 24

Specifications A-1

Startup, Initial 32

Storage 7

T

Theory of Operation 35

torque, tightening 24

Touchscreen

 menu tree 34

U

UPS

 Discharge Process 37, 38, 39

UPS functional overview 35

UPS stop signal input 49

V

ventilation 27

Volume, Buzzer. *See* Buzzer Volume

W

warning labels 3

Warranty c, d, 7

Weights, shipping 60

Weights, UPS 60

TOSHIBA

**TOSHIBA INTERNATIONAL CORPORATION
SOCIAL INFRASTRUCTURE SYSTEMS GROUP
POWER ELECTRONICS DIVISION**

13131 West Little York Road, Houston, Texas 77041
Tel (713) 466-0277 Fax. (713) 896-5212
US (855) 803-7087 Canada (800) 872-2192

www.toshiba.com/tic/industrial/uninterruptible-power-systems

Printed in the U.S.A.